









# ASSEMBLY INSTRUCTION

## REVERSIBLE SOFA CHAISE W/2 PILLOWS

**NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.**


### COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
A		3	BACK CUSHION
B		1	SOFA FRAME
C		1	OTTOMAN FRAME
D		1	CHAISE SEAT CUSHION
E		2	SEAT CUSHION
F		2	PILLOWS
G		8	GASKET
H		8	PLASTIG LEG


**Please follow the drawings below to assemble the item.**

Plastic legs are packed in bubble bag and stored in the bottom of the unit. please take out for assembly.

**Step 1.** Insert the gasket onto the plastic legs, align the legs to the pre-drilled holes at the bottom of sofa and chaise, rotate to tighten it.




**Step 2. Completed**



### **CARE INSTRUCTION FOR PU AND LINEN-LIKE FURNITURE:**

In order to maintain the original appearance of your PU and Linen-Like furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage PU and Linen-Like Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Vacuum or wipe with a soft brush to remove dust.
- Clean fabric PU and Linen-Like with professional cleanser.

 For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.