


TV stand




2 Persons


L2000*W400W*H550mm

Installation Instructions









Notes: Don't tighten screws completely at first, just in case parts were assembled wrongly and need disassemble. Tighten screws at last when all parts are put together.












Disassembly and installation of accessories








A 46PCS  15*10mm	B 46PCS  6*28mm	C 16PCS  3.5*14mm	D 4PCS  Three-section Rail	E 8PCS  3.5*40mm	F 28PCS  8*30mm	G 14PCS  φ 15mm	 Tools Recommended
H 4PCS 	I 16PCS  4*12mm	J 8PCS 	K 11PCS  4*40mm	L 2PCS 			

1  3PCS	2  1PCS
3  1PCS	4  2PCS
5  1PCS	6  1PCS
7  1PCS	8  1PCS

9  1PCS	10  1PCS	
11  2PCS	12  2PCS	13  2PCS
14  2PCS	15 16  1PCS	
17  2PCS	18  2PCS	

1




B	46PCS
	
6*28mm	

2

Dx4

D₁


D₂





D ₁	4PCS
	
Three-section Rail	

3


D₁x4



D₁x2
Cx4



D₁x1
Cx2




D₁x1
Cx2

C	8PCS
	
3.5*14mm	


D ₁	4PCS
	
Three-section Rail	

4




A	6PCS
	
15*10mm	

5




A	14PCS	F	14PCS
			
15*10mm		8*30mm	

6




A	6PCS	F	6PCS
			
15*10mm		8*30mm	

7




K	11PCS	L	2PCS
			
4*40mm			

8




A	12PCS	F	8PCS
			
15*10mm		8*30mm	

9




G	14PCS
	
φ 15mm	


10



11




12



C	16PCS	I	16PCS	J	4PCS	K	8PCS
							
3.5*14mm		4*12mm					

13



OK