








Dining Chair



PART LIST


#A 	#B 	#C 	#D 	#E 
Back 2 PCS	Seat 2 PCS	Front Leg 2 PCS	Side Rail 4 PCS	Stretcher 4 PCS

HARDWARE LIST

#1  M6 x 50mm	#2  1/4"	#3  M4 x 32mm	#4  M4
Bolt 16 PCS (Extra 2)	Spring Washer 16 PCS (Extra 2)	Screw 16 PCS (Extra 2)	Allen Wrench 1 PC

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Step 1 . Attach side rails (part D) to back (part A) using bolts (part #1), spring washers (part #2) and allen wrench (part #4). See Figure 1. Attach stretchers (part E) to back (part A) using screws (part #3) and phillips head screwdriver. See Figure 2.

NOTE: Please do not fully tighten bolts until unit is fully assembled.





Figure 1

Figure 2


- | | | |
|----|--|----|
| #1 | | x4 |
| #2 | | x4 |
| #3 | | x2 |
| #4 | | x1 |

Step 2 . Attach front leg (part C) to side rails (part D) and stretchers (part E) using bolts (part #1), spring washers (part #2), screws (part #3), allen wrench (part #4) and phillips head screwdriver.

NOTE: Please fully tighten all bolts at this time.



Step 3 . Attach seat (part B) to assembled unit (parts A, C, D & E) using screws (part #3) and phillips head screwdriver.



#3  x4

Step 4. Carefully turn unit upright. Repeat steps 1-3 to assemble remaining chair.

