


Assembly Directions for Octagon Picnic Table

Model #POPT-5184


- Step 1** Place the four (4) seat/leg sections in a square as shown.




- Step 2** Locate the stainless steel plate in your hardware package, align ends of opposite seat/leg sections with plate (as shown **A**), and fasten plate using 1" screws. This will tie all four sections together. Add second plate to bottom side of seat/leg sections, using the same fastening method.



- Step 3** Place the table top on the seat/leg sections. Then fasten top using one (1) $\frac{5}{16}$ " x 2" Allen Head bolt per leg (upright).



- Step 4** Enjoy your completed picnic table!



Use to measure bolts

PACKAGE CONTENT

- 1 Top
- 4 Legs
- 2 Metal Plate
- 1 Hardware Package

Tools Needed:

- Hammer,
- Screw Gun,
- $\frac{1}{2}$ " Wrench
- Allen Wrench (Included)

HARDWARE PACKAGE

- 48 1" Screws
- 4 $\frac{5}{16}$ " x 2" Allen Head Bolts
- 4 $\frac{5}{16}$ " Flange Nuts
- 1 Allen Wrench

