


















**Caution:** This instruction manual is intended for universal reference, slight variations in part dimensions are normal.



COMPONENT

①	②	③	④	⑤	⑥	⑦	⑧
							
X4	X4	X4	X2	X12	X16	X1	X1

P1	P2	P3
		
X2	X1	X1


P4	P5	P6
		
X2	X1	X1

P7	P8	P9
		
X1	(Stickers) X1	X2

P10	P11
	
X2	X2


1

③ x 4




2


① x 4  
② x 4  
④ x 2




3




4



5



6



7

