








3-Seat Porch Swing
Assembly Instructions












Before You Start

- ◎ Please read all instructions carefully.
- ◎ Retain instructions for future reference.
- ◎ Separate and count all parts and hardware.
- ◎ Read through each step carefully and follow the proper order.
- ◎ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ◎ Always place the product on a flat, steady and stable surface.
- ◎ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Package Parts List

A1		1
A2		1
B		4
C		2
C1		2
D1		1
D2		1
E		2
E1		2
F		2
G		1
H		2
J		1
K		3


L			1
M			2
N			2
O		M8*100	4
P		M6*90	4
Q		M8*83	2
R		M8*75	4
S		M6*70	2
T		M8*30	2
U		M6*28	1
U1		M6*20	8
V			8
W		M6*7 	M8*10
X		M6*7 	M8*10
Y		M6*7 	M8*10
Z			2
Z1			1

Assembly Guide

Please distinguish the type & quantity of screws in each step, as enlarged view shown for details.


STEP 1

Assemble Part A1 and A2.




STEP 2

Connect up with Part B, C and C1.




STEP 3

Connect up with Part F.




STEP 4

Assemble Part D1 and D2.




STEP 5

Connect up with Part D1 and D2.




STEP 6

Assemble Part H, E1, and G.




STEP 7

Connect up with Part E.




STEP 8

Connect stand frame and chair part with Part N.



STEP 9

Connect up with Part J.



STEP 10

Connect Part K and Put on Part L.

