


# Instruction Manual

## SKU:AKG3-D



1. Never keep emergency keys and emergency battery box in your gun cabinet!!!
2. When you receive a cabinet, you must set your code immediately!!!


# CATALOGUE & WARNING



|                                                  |       |
|--------------------------------------------------|-------|
| Cabinet Exploded View & Part List .....          | 1     |
| Installation .....                               | 2-8   |
| Cabinet Display .....                            | 9     |
| Cabinet Settings and Function Introduction ..... | 10-12 |

# Exploded View & Part List

## Tips

1. Please read the complete installation instructions carefully before assembling the gun cabinet.
2. Check the materials to make sure they are normal and not damaged.
3. Refer to the illustrations to identify the parts and accessories of the gun cabinet.
4. Align the holes and tighten the screws during installation.
5. Installation requires two people, and keep children away to avoid accidental injury.



|                                                                                   |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|    |    |    |    |    |    |    |    |  |
| ①                                                                                 | ②                                                                                   | ③                                                                                   | ④                                                                                   | ⑤                                                                                   | ⑥                                                                                   | ⑦                                                                                   | ⑧                                                                                   | ⑨                                                                                   |
| (Left Side Plate)<br>1PC                                                          | (Left Back Plate)<br>1PC                                                            | (Right Back Plate)<br>1PC                                                           | (Right Side Plate)<br>1PC                                                           | (Upper Door Frame)<br>1PC                                                           | (Bottom Door Frame)<br>1PC                                                          | (Top Plate)<br>1PC                                                                  | (Bottom Plate)<br>1PC                                                               | (Middle Vertical Plate)<br>1PC                                                      |
|  |  |  |  |  |  |  |  |                                                                                     |
| ⑩                                                                                 | ⑪                                                                                   | ⑫                                                                                   | ⑬                                                                                   | ⑭                                                                                   | ⑮                                                                                   | ⑯                                                                                   | ⑰                                                                                   |                                                                                     |
| (Shelf)<br>4PCS                                                                   | (Left Compartment Divider)<br>1PC                                                   | (Right Compartment Divider)<br>1PC                                                  | (Metal Storage Box)<br>4PCS                                                         | (Left Door Plate)<br>1PC                                                            | (Right Door Plate)<br>1PC                                                           | (Gun Stock)<br>1PCS                                                                 | (Gun Stock)<br>2PCS                                                                 |                                                                                     |

|                                                                                    |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                     |                                                                                       |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  |  |  |  |  |  |  |  |  |  |  |
| A                                                                                  | B                                                                                   | C                                                                                   | D                                                                                   | E                                                                                   | F                                                                                   | G                                                                                   | H                                                                                   | I                                                                                   | J                                                                                   | K                                                                                     |
| (Expansion Screw)<br>4 PCS                                                         | (Screw)<br>86 PCS                                                                   | (Triangular Iron Sheet)<br>4 PCS                                                    | (Metal Piece)<br>4 PCS                                                              | (Top Buckle)<br>16 PCS                                                              | (Bottom Buckle)<br>16 PCS                                                           | (Gasket)<br>2 PCS                                                                   | (Door Hinge)<br>2 PCS                                                               | (Adjustment Foot)<br>2 PCS                                                          | (Screwdriver)<br>1 PC                                                               | (Sensor Light)<br>1 PC                                                                |


# Installation Instructions

## ⚠ WARNING



- Tip over hazard: Secure the cabinet! The cabinet can be tipped over by children or adults, please make sure the cabinet is mounted on the wall.
- Keep the keys in a secure place away from children.
- Do not move this cabinet using its handle.


1



### Step 1 Left Plate Installation

Fix ① and ② with four B's.


2



### Step 2 Back Plate Installation

Fix ② and ③ with five B's.


3



### Step 3 Right Plate Installation

Fix ③ and ④ with four B's.


4



### Step 4 Door Frame Installation

Put ⑤ and ⑥ in the positions as shown in the figure, and fix them from the inside with eight B's.


5



### Step 5 Top Plate Installation

Install the ⑦ by inserting it from front to back and secure with nine B's from inside.

6




### Step 6 Bottom Plate Installation

Put ⑧ on the bottom, and fixed from the outside with five B's.

#### NOTICE:

Please lay the cabinet flat and adjust the feet to the same height as the surrounding area to increase the bearing capacity of the cabinet.


7



#### Step 7 Triangular Iron Sheet Installation.

Please lay the cabinet flat. At the four corners of the outer bottom plate, there are sixteen pre-drilled holes. Fix the bottom plate with sixteen B's and four C's, as the picture shows.


8



#### Step 8 Fix the Bottom Plate

At the four corners of the interior bottom plate, there are eight pre-drilled holes. Fix the bottom plate with eight B's and four D's, as the picture shows.

9




### Step 9 Mount the Cabinet


Fix the cabinet on the wall with four A's.

#### NOTICE:

We suggest that you could mount the cabinet on the wall to prevent it from falling. If you choose to do so, do it in this step.




10



### Step 10 Middle Vertical Plate Installation

Install ⑨ and fix it in the back and bottom with five B's.


# 11



## Step 11 Shelf Installation

Fix ⑩ on both sides with four E's and F's, "E" on the top and "F" on the bottom, then install ⑩ wherever you want, and you can adjust the position as needed.


# 12



## Step 12 Compartment Dividers Installation

- 1) Fix ⑪ on left side with four B's, then place ⑫ on the right side.
- 2) You can install the K's in any position you want (The sensor light requires three AAA batteries, it will light up when the door is open or object sensed).
- 3) Install ⑬ on the back, ⑭ on the left and right side.


13



### Step 13 Metal Storage Box Installation

Fix ⑬ and ⑭ with sixteen B's.

14




### Step 14 Door Plate Installation

1) Slide H through G, then insert the upper end of H into the bottom-left hinge hole of ⑭. Align and secure the lower end of H into the corresponding bottom hinge hole on the base plate. With the door panel slightly tilted downward (approximately  $10^{\circ}$ – $15^{\circ}$ ), press firmly on the spring mechanism inside the top-right hinge hole of ⑭ with your finger. Gently lift the door plate, slowly release the spring tension—the installation is successful.

2) Fix ⑮ in the same method.

# Cabinet Display




## Warnings

1. Do not lock the emergency key or emergency battery box into the cabinet.
2. The initial user code is **123456**, which need to be modified.
3. If the cabinet is not used for a long time, the battery should be removed to prevent leakage of liquid from damaging the electronic system.
4. Purchase 4 AA batteries in advance, this cabinet does not include batteries.

# System Setting

## ► Step1 Open the door with the key



1. Press the right side of the keyhole cover to expose the emergency keyhole.
2. Insert the emergency key, turn it counterclockwise to the limit, and hold on it.
3. Then rotate the handle clockwise to open the door.

**⚠ NOTICE:** 1. When you rotate the handle to open, you must have the key fully inserted and turned counterclockwise to the limit, keeping the key until the safe unlocked and opened.

2. Use the key to unlock, the led light will not light up.
3. Please keep the keys in a secure place, do not lock the keys inside the safe.

## ► Step2 Install Battery

1. After first opening, keep the safe open and locate the battery case, prepare 4 brand-new AA 1.5 Volt alkaline batteries (not included).
2. Remove the internal battery case cover and install the 4 AA batteries by matching the + & - electrode.


**⚠ NOTICE:** 1. Rechargeable battery is not recommended as it may destroy the internal electronic components of your safe.

2. Please use brand-new batteries, do not mix used batteries with new batteries.
3. After opening the door, if the safe beeps 6 times in a row, it means the batteries are out of power, please replace the batteries.

## ► Step3 Set the first code

**⚠ NOTICE:** To set the code, quickly press the setting button briefly. Do not press and hold the setting button, as holding it for more than 3 seconds will reset all codes.

1. Open the safe, keep the safe opening, short press the setting button (on the inner side of the door), the safe beeps once and keypad light on.
2. Input a new code(3-12 digits),then press **#** to confirm. The buzzer plays a chord, indicating that the code is successfully set.
3. Testing the code before you close the door.



#### ➤ **Step4 Set the second code**

**⚠ NOTICE:** To set the code, quickly press the setting button briefly. Do not press and hold the setting button, as holding it for more than 3 seconds will reset all codes.

1. Open the safe, keep the safe opening, press **#** to activate the keypad, enter 0 twice, then short press the setting button (on the inner side of the door), the safe beeps once and keypad light on.
2. Input a new code(3-12 digits),then press **#** to confirm. The buzzer plays a chord, indicating that the code is successfully set.
3. Testing the code before you close the door.

**⚠ NOTICE:**

1. 10 seconds without any operation after pressing the setting button, it will go back to standby mode, you need to set it again.
2. Please set up both of two codes immediately after receiving the safe.
3. The default code is **123456**, need to be modified.

## Three Ways to Open the Door

### **1. The first unlocking method: Use the emergency key**

Insert the emergency key into the right keyhole, turn counterclockwise to the limit, then rotate the handle clockwise to open the safe (Suitable for the first opening, forget code or weak battery).

### **2. The second unlocking method: Use the user code**

After installing the battery, press **#** to activate the keypad, enter your code and then press the **#** key to confirm, rotate the handle clockwise to open the safe (Suitable for quick access and daily use).

### **3. The third unlocking method: Use the emergency battery box + user code**

When the battery of your safe is weak and you can't find the keys, please insert 4 AA batteries in the emergency battery box, plug the emergency power cord into the emergency power jack, then enter the correct code to open the door (Suitable for the battery is out of power and the key can not be found).

## Dual Alarm System

1. After 3 consecutive times of wrong code, your safe will activate the alarm system, the alarm will sound for 30 seconds, enter the correct code and the alarm will be cancelled.
2. In standby state, press **#** to activate the keypad, then press **\***, the buzzer makes a long beep and the keypad light goes off, the vibration alarm mode is turned on. If the box is shaken or violent hit, it will give an alarm immediately for 30 seconds, at this point, enter the correct code to stop the alarm.

### NOTICE:

1. When power on, the system default for alarm is off.
2. After safe is opened with code, the vibration alarm will be turned off and needs to be turned on again.

## Mute Function

1. In standby state, press **#** to activate the keypad, press **1** twice, then press **#**, there is a long beep, indicate the mute function is turned on.
2. In mute function state, press **#** to activate the keypad, press **1** twice, then press **#**, there is a long beep, indicate the mute function is turned off.

### NOTICE:

Under the mute function, the wrong code alarm and vibration alarm still work, and the alarm will sound when triggered.

## Reset the System

1. Press and hold the setting button for 3 seconds, the buzzer plays a chord, the green light on the left comes on, indicating the reset successful (All stored codes will be deleted, please use the default code to unlock).
2. The default code is **123456**, need to be modified.