

PARTS

(1)X1	(9)X1
(2)X1	(10)X1
(3)X1(L)X1(R)	(11)X10
(4)X1	(12)X2
(5)X1	(13)X1
(6)X1	(14)X10
(7)X1	(15)X2
(8)X5	(16)X1

ASSEMBLY INSTRUCTION

1

2

3

4

5

6

7