



Instructions for using fan lights



The remote control must be coded before use, and the fan and other remote control functions can be used normally

Code: Turn on the power switch, long press the "code" key within 3 seconds after hearing a "beep" sound, and the receiver emits two "beep" codes successfully. If the code alignment fails, turn off the power and repeat for one minute.

Clear code: Turn on the power within 3 seconds, long press the total key, hear the "drip drip" ring three times, the light flashes three times off, the clear code is completed.

Warm reminder:

If the remote control is not effective: Check the battery. Take out the battery if it is not used for a long time.