



Each piece of the sectional will have either a male or a female connector attached to the bottom. You pick up the piece with the male connector and align it with the piece with the female connector. Once in place lower the male connector into the female connector in order for the connectors to lock into position. To unconnect follow the same procedure but in reverse. Lift the piece with the male connector to unlock the 2 pieces.