

ASSEMBLY INSTRUCTIONS

IMPORTANT **PLEASE READ BEFORE YOU CONTINUE FURTHER**

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples, and packing straps from the carton.
2. Refer to the Parts List and Hardware List to ensure all parts and hardware are correct before starting assembly.
3. Place all wooden parts on a clean, flat, and soft surface (e.g., carpet or rug) to prevent scratches and damage.

SAFETY PRECAUTIONS

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE OF PLASTIC PACKAGING MATERIALS IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

1. Ensure ample space for assembly and position the area close to where the product will be placed.
2. Assemble the product on a surface that will not scratch or damage the exterior gloss or finishing of the furniture.
3. Identify all parts, hardware, and quantities required for each step.
4. Avoid over-tightening any fittings during assembly, as this may cause damage.
5. Use hand tools only--DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always assemble the product on a flat, level surface.
7. Assembly requires two or more people--do not attempt to assemble the product alone, as there is a risk of injury.
8. Do not sit or stand on the partially assembled product. Use the product only for its intended purpose.

WARNINGS





1. This product is intended for indoor and household use only, and is not suitable for commercial use.
2. Stools are designed for normal use with all four legs on the ground. Do not sit in the stools with only two legs on the ground (e.g., tipping back, forward, or sideways), as this may stress and damage the stool legs.
3. Do not stand on the stool.






- DO NOT STAND ON THE STOOL
- DO NOT SIT IN THE STOOL WITH ONLY TWO LEGS

Please make sure you have all these parts before you start.


PART LIST

Ⓒ x 1pc 	Ⓗ x 4pcs 
Ⓘ x 2pcs 	Ⓙ x 2pcs 


HARDWARE LIST


③ x 1pc  ALLEN KEY M4 (BALL SHAPE)	⑥ x (8pcs +1)  JCBC M6 x 60mm + S/W M6 + F/W M6 x 19mm	⑦ x (8pcs +1)  PH CB SCREW M4 x 38mm
 NOT PROVIDED		

(Extra Hardware for spare use)




STEP 1


6	 JCBC M6 x 60mm + S/W M6 + F/W M6 x 19mm	4PCS
---	--	------




STEP 2


6	 JCBC M6 x 60mm + S/W M6 + F/W M6 x 19mm	2PCS
---	--	------

Make sure the screw hole of Rail **I & **J** face Downward**




STEP 3

6	 JCBC M6 x 60mm + S/W M6 + F/W M6 x 19mm	2PCS
---	--	------



STEP 4



Steps to Check and Fix Stool Stability

1. Initial Check for Wobbles:

- Place the stool on a level surface.
- Check if the stool wobbles.
- If wobbling is detected, perform the Drop Test.

2. Lift the Stool:


- Lift the chair 30mm to 50mm off the ground.
- Ensure your feet and toes are well away from the drop zone.
- Drop the stool freely and vertically so all four legs hit the ground simultaneously.
- This test helps realign all parts and gaps into their proper positions.

3. Tighten Bolts and Screws:


- Tighten all bolts and screws.
- Tighten bolts and screws sequentially, using an alternating pattern.
- Avoid fully tightening any bolt or screw at once, as this can cause the frame to warp.

STEP 6

7	 PH CB SCREW M4 x 38mm	8PCS
---	--	------



**Fully tighten the screw
but do not over-tighten.**



STEP 7

