

User's Manual

Thank you for purchasing this quality Product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. identify and count all parts and compare with the parts list below.











ASSEMBLY INSTRUCTION:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered above for fast and easy assembly.


WARNING!

1. Do not attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time 1/2 hours.
5. Component parts and fittings contained in the box. Please sort out all parts before you begin to assemble the item. This is to make sure you always use the correct part.
6. It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product to your wall. Tipping furniture can cause serious injuries and death. To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wall or other solid surface, using the anchor straps provided appropriate fixings.

No.	Component		Q'ty
A		Sink	1
B		Side Panel-Left	1
C		Side Panel-Right	1
D		Middle Panel	1
E		Bottom	1
F		Fake drawer	1
G		Back Panel	1
H		Back Panel	1
I		Front Rail	1
K		Door	1
L		Drawer Front	2
M		Drawer Side	4
N		Drawer Back	2
O		Drawer Bottom	2


No.	Hardware		Q'ty
1		Cam Lock	20
2		Cam Lock Screw	20
3		Wooden	38
4		Angle Bracket	2
5		Screws Ø3.5x12	8
6		Knob	5
7		Screws Ø4x20	3
8		Screws Ø4x25	2
9		Screws Ø3x15	4
10		Screws Ø4x25	16
11		Door Magnet	1
12		Screws Ø3.5x15	2
		Not Included	

Step 1




No	Hardware	Q'ty
2	Cam lock Screw	20

Step 2




No	Hardware	Q'ty
3	Wooden	3

Step 3




No	Hardware	Q'ty
1	Cam Lock	4

Step 4




No	Hardware	Q'ty
3	Wooden	4

Step 5




No	Hardware	Q'ty
1	Cam Lock	1

Step 6




No	Hardware	Q'ty
11	Door Magnet	1
12	Screws 3.5x15	2

Step 7




No	Hardware	Q'ty
3	Wooden	2

Step 8




No	Hardware	Q'ty
1	Cam Lock	3

Step 9




No	Hardware	Q'ty
3	Wooden	6


Step 10




No	Hardware	Q'ty
1	Cam Lock	4

Step 11


No	Hardware	Q'ty
3	Wooden	7

Step 12

No	Hardware	Q'ty
1	Cam Lock	6


Step 13

No	Hardware	Q'ty
1	Cam Lock	2

Step 14


No	Hardware	Q'ty
4	Angle Bracket	1
5	Screws 3.5x12	4

Step 15




No	Hardware	Q'ty
4	Angle Bracket	1
5	Screws 3.5x12	4

Step 16




No	Hardware	Q'ty
9	Screws 3x15	4

Step 17



No	Hardware	Q'ty
6	Knob	3
7	Screws 4x20	3


Step 18



No	Hardware	Q'ty
3	Wooden	16
10	Screws 4x25	16


Step 19

Drawer x2




No	Hardware	Q'ty
6	Knob	2
8	Screws 4x25	2


Step 20



Step 21



Step 22



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING:

- Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;
- For your safety, please do not tread or climb product.
- The loading weight shall be within the range that vendor claims. The product is designed for adults use, domestic use and indoor use only.
- The product shall not combine with other product for use.
- If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators
- Check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing
- Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions:

- Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.
- A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.
- Keep the assembly instructions available at all times and follow each of the individual steps exactly.
- During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.