# BOOKCASE ASSEMBLY INSTRUCTIONS



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



# Warning!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.





# ASSEMBLY TIME | 40 MINUTES

### **PARTS IDENTIFICATION:**



Z	HARDWARE IDENTIFICATION										
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY				
1	GLUE 40g		1PC	5	BOLT (\$\phi 9.5x55mm SR) FOR BOTTOM PANEL	and the second	24PCS				
2	WOODEN DOWEL φ8x30mm		48PCS	6	FOOT 50x50x18mm		5PCS				
3	CAM BOLT (Ø7x35.5mm SR)		24PCS	7	SCREW FOR FOOT (Ø5x22.5mm BLK)		10PCS				
4	CAM LOCK (\$\phi 15x12mm SR)		24PCS	8	STICKER Ø20mm		4PCS				

Z	HARDWARE IDENTIFICATION									
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY			
9	ANTI-TIP STRAP 170x15mm		2PCS	11	WALL SCREW (Ø4x25mm SR)	ATTITUTE A	2PCS			
10	WALL PLUG 6x30mm	and the second	2PCS	12	SCREW (Ø4x16mm SR)	and a	2PCS			

