

Assemblage-Anweisung

Ax1 	Kx1 
Bx1 	Lx1 
Cx1 	Mx10  M6x12mm
Dx2   D1 D2 5psc	Nx4  M6x20mm
Ex5 	Ox20  M6x25mm
Fx1 	Px4  M8x20mm
Gx2 	Qx1  M5x8mm
Hx2 	Rx1  M6
Ix2 	Sx2   S1 S2
Jx1 	

