



Assembly Manual of Sit-Stand Desk



PLEASE DO NOT RETURN TO STORE




Please do not return this product to the retailer!
We are able to assist you in ANY way!


If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.



















Please carefully review the following precautions before proceeding with the installation:

- 1.The installation process for this product is complex, and it is highly recommended to have at least two individuals working together during the installation.
- 2.Prior to each step, please refer to the screw hole positions to ensure that the board is aligned correctly according to the images provided in the instruction manual. This will help prevent any errors.
- 3.In case power tools are used for installation, it is important to tighten the screws intermittently rather than applying excessive force continuously. This precaution will help avoid potential cracks around the screw holes.
- 4.If you encounter any difficulties or issues during the assembly process, please don't hesitate to reach out to us via email or Amazon message. We assure you that we will address your concerns and provide a solution within 24 hours.


Thank you for your attention to these important instructions.






① ×2 	② ×3 	③ ×1 
④ ×1 	⑤ ×1 	⑥ ×1 
⑦ ×1 	⑧ ×1 	⑨ ×1 
⑩ ×1 	⑪ ×2 	⑫ ×1 
⑬ ×1 	⑭ ×1 	⑮ ×1 
⑯ ×1 	⑰ ×1 	⑱ ×1 








19×1



















20×1





Correct Installation Method for Three-in-One Connector



Hardware



A	×36	B	×36	C	×36
					
D	×80	E	×4	F	×2
 Ø3.5*14mm		 Ø3.5*40mm			
G	×2	H	×2	I	×10
					
J	×4	K	×1	L	×2
					
M	×2	N	×2	O	×1
					
P	×4	Q	×1	R	×1
					

A	×20	B	×20	C	×20
					





STEP1

A	×10	B	×10	C	×10
					





STEP2

A	×4	B	×4	C	×4
					





STEP3





STEP4

A	×4	B	×4	C	×4
					





STEP5

A	×4	B	×4	C	×4
					





STEP6

A	×10
	





STEP7



A	×4	B	×4	C	×4
					



STEP8





STEP9




STEP10

A	×4	B	×4	C	×4
					





STEP11




L	×2
	







STEP12





STEP13



STEP14



STEP15



STEP16

1

Valve switch
(press down to open)

Note: remove a and B first

2

side board
after


3

sideboard
of the drawer
after

4


Note: align B with a
and push it in
three-section ball rail

D	×2	H	×1
			
Ø3.5*14mm			




STEP17

Q	×1
	




STEP18


D	×2	H	×1
 Ø3.5*14mm			




STEP19



STEP 20



STEP21




Note: align B with a
and push it in
three-section ball rail

How to Change Password

1. Enter your existing password or factory default password **【000】** .
2. Move the slider from A to B.
3. Hold the slider at B and set your new password.
4. Return the slider back to A once new code is set.




D	x2	H	x1
			
Ø3.5*14mm			




STEP22

D	x2	H	x1
			
Ø3.5*14mm			




STEP23


D	x2	K	x1
 Ø3.5*14mm			



STEP24




STEP25





STEP26

D	×2	N	×1
			
Ø3.5*14mm			





STEP27

D	×2	N	×1
 Ø3.5*14mm			





STEP28

D	×4	F	×2
 Ø3.5*14mm			




STEP29

D	×4	G	×2
 Ø3.5*14mm			




STEP30




STEP31

D	×4
	
Ø3.5*14mm	




STEP32

D	×4
	
Ø3.5*14mm	




STEP33

O	×1
	








STEP34



STEP35

PARTS LIST



①  X1	②  X1	③  X1	④  X4	⑤  X2
⑥  X2	⑦  X2	⑧  X1	⑨  X1	⑩  X1
A  X1	B  X1	C M6X35  X8	D M6X12  X20	E ST4X14  X10
F M6X10  X4	G 5mm  X1	H  X3	I  X4	



Operating instructions



1. Reset: Press  and hold the key to reset at the lowest position for a long time.
2. Short press the number keys to run to the set height, and press any key to stop running during operation.
3. Memory position save: Run the desktop to the desired position, press the corresponding number key, the display screen flashes, and the current height is stored to the corresponding number key.

D		M6×12(×12)
G		




STEP36


C		M6×35(×8)
A		




STEP37




STEP38



STEP39




STEP40




STEP41

D	 M6×12(×8)
A	




STEP42


D	×6
	
Ø3.5*14mm	



STEP43




STEP44




STEP45

M	×2	P	×4
			




STEP46



STEP47

R	×1
	



STEP48