

Assembly Instructions



60" SPARKLER SNOWFLAKE

ITEM # 68018 & 68022



PARTS LISTING:
EACH 60" SPARKLER SNOWFLAKE
CONTAINS:

- (6) SNOWFLAKE ARMS
- (1) CENTER SNOWFLAKE
- (6) SET SCREWS
- (1) WRENCH

ASSEMBLY:

Carefully remove all items from the box and remove any packing materials.



STEP 1:
Remove all 7 Snowflake pieces, wrench, screws, and controller.



STEP 2:
Plug in each arm of the snowflake to center arm.



STEP 3:
Tighten each screw firmly with included wrench



STEP 4:
Plug the male plug at the base of the snowflake into a UL approved extension cord or outlet

STEP 5:
Place item where you want it displayed. If you are using wire or cable, please make sure it is strong enough to hold the snowflake in place and will be resistant to any inclement weather conditions.

STEP 6:
Plug assembled Snowflake into a UL approved extension cord or directly into an outlet.

STORAGE:

At the end of the season, remove the item and unwanted hanging materials. Place in original packaging and store in a cool, dry place.

CARE INSTRUCTIONS:

To maintain this item's pristine condition, wipe product with a clean, soft, dry towel and store in a cool, dry place.

FOR ADDITIONAL ASSISTANCE:

Please contact one of our Product Specialists for assembly assistance or questions at 1-855-505-6046 Specialists are available weekdays 9:00AM to 5:00PM CST.