



Assembly Instruction



If you have any questons, please contact us
We will help you with in 24 hours









We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.




Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.



Instructions For Fastening
CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head

CORRECT

WRONG

Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK



Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.


The Hardwares

A	X18
	
M6x35mm	

B	X18
	
Ø15x9mm	

C	X39
	
M3.5x12mm	

D	X10
	
M3x16mm	


E	X1
	
4mm	


F	X23
	
M4x12mm	

G	X17
	
Ø8x30mm	

H	X2
	
M4x20mm	


I	X2
	

J	X13
	
M5x40mm	

K	X2
	
M4x35mm	

L	X1
	

M	X2
	


N	X2
	
Ø6x30mm	

O	X1
	
M6x12mm	


P	X8
	

Q	X4
	
M6x30mm	

R	X2
	
M8x30mm	


S	X4
	

T	X4
	
M8x15mm	

U	X1
	


V	X1
	


W	X2
	


X	X2
	


Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.


























⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for free replacement if having damaged or missing parts.

① 	② 	③ 	④ 
1PC	1PC	1PC	1PC
⑤ 	⑥ 	⑦ 	⑧ 
1PC	1PC	1PC	1PC
⑨ 	⑩ 	⑪ 	⑫ 
1PC	1PC	1PC	2PCS
⑬ 	⑭ 	⑮ 	⑯ 
1PC	1PC	4PCS	1PC
⑰	⑱ 		
4PCS	1PC		

1






M	X2

F	X2
M4x12mm	


A	X8
M6x35mm	

2




C	X4
M3.5x12mm	


3



C	X2
	
M3.5x12mm	

4




X	X2
	

C	X9
	
M3.5x12mm	


L	X1
	


5



G	X1
	
Ø8x30mm	


6





A	X2
	
M6x35mm	


7



A	X2
M6x35mm	

F	X5
M4x12mm	


8




B	X4
Ø15x9mm	

G	X2
Ø8x30mm	

9







B	X8
Ø15x9mm	

G	X4
Ø8x30mm	

10



11




U	X1
	


D	X2
	
M3x16mm	

A	X6
	
M6x35mm	

12



13





Q	X2
M6x30mm	

G	X2
Ø8x30mm	

J	X7
M5x40mm	

14







B	X6
Ø15x9mm	

G	X4
Ø8x30mm	

15




16



G	X4
	
Ø8x30mm	


J	X6
	
M5x40mm	

17




F	X16
	
M4x12mm	

18




T	X4
	
M8x15mm	

19




I	X2
	


H	X2
	M4x20mm

S	X4
	

C	X8
	M3.5x12mm


20








C	X8
	M3.5x12mm


21













C	X8
	
M3.5x12mm	


22





R	X2
	
M8x30mm	


23



Insert screws O and tighten to 40% (do not fully lock).

O	X1
	
M6x12mm	


24



Secure component V and lock component O.


V	X1
	

25



W	X2
	


26




P	X8

D	X8
	M3x16mm

27





N	X2
Ø6x30mm	

K	X2
M4x35mm	

