



Ax1



Bx1



Cx1




Dx1




Ex1




①



②



③



④

**Note: the white wire match the white one
the red wire match the red one
the black wire match the black one**

- Do not allow children to play on the chair.
- Always leave the chair in an upright and closed position after use.
- Keep hands and feet clear of the mechanism.
- Only the occupant should operate the chair.
- Keep the front of foot rest area clear while extending to prevent any injury