


# **Kitchen Patio Garden**

## **Assembly Instructions**






**End Panel - AA (2 pieces)**  
**Side Panel - BB (2 pieces)**  
**Bottom Panel - CC (1 piece)**


To assemble your *Kitchen Patio Garden*, you need only a philips screwdriver.

## Step 1



Attach **End Panel - AA** to **Side Panel - BB** using supplied 3" screws, being careful to align inside and top edges of *Support Cleats*.


## Step 2




Attach second **End Panel - AA** to **Side Panel - BB** using the supplied 3" screws, again carefully aligning the inside and top edges of the *Support Cleats*.

## Step 3

Attach *Assembly from Step 2* to second **Side Panel - BB** using the supplied 3" screws, while carefully aligning the inside and top edges of the *Support Cleats* on both sides.




## Step 4



Insert **Bottom - CC**  
(landscaping cloth up) onto  
*Side Panel Support Cleats*

## Step 4b



Secure **Bottom - CC** to *Side Panel Support Cleats* using the supplied 1 1/4" screws.

The 6 pilot holes for the 1 1/4" screws are found around the edge of the **Bottom - CC** and can be accessed by carefully lifting the edge of the landscaping cloth. Inserting the screws *through* the landscaping cloth is *not recommended*.