

Thermo Outdoor Kitty House (Heated or Unheated)

Care & Instructions

PUTTING TOGETHER YOUR Thermo Outdoor Kitty House

1 Locate the roof panel, the house structure with the floor and 4 side panels, and the padded floor. See **Figure 1**.

2 Raise up both side walls and the **front door end panel on the front of the house** to meet one another. First, make sure to identify the front door panel from the back door panel. **TIP:** The front door panel contains a color logo patch, while the back door panel does not. See **Figure 2a**.

Once those 3 panels are upright, line up the hook and loop material sewn along the edges and press firmly to fasten them together. See **Figure 2b**. Leave the back door end panel open at this time.

3 Next, locate the hook and loop material on the underside of the roof panel. Firmly attach it to the tops of the house structure (front door end panel and both side panels that were just assembled). Press all hook and loop firmly for good adhesion. See **Figure 3**.

4 *If you purchased the heated version*, follow instructions on the back to set-up your heated pad.

Place the unheated or heated pad into the open back door panel on the bottom floor of the house structure prior to closing the back door of the house. For the heated version, thread the cord through the cord hole. See **Figure 4a, 4b, 4c**.

5 Optional clear door flaps can be removed or attached from the inside using the hook and loop material. Adjust doors to ensure free swinging. Press firmly. See **Figure 5**.

6 To close your house, attach the remaining back door end panel to the hook and loop material on the underside of the roof panel and to the 2 side panels. Press firmly for good adhesion. See **Figure 6**.

**If you purchased the heated version*, follow instructions on the back for the patented heated pad.




Figure 1




Figure 2a

Logo Patch on Front of House




Figure 2b



Figure 3

Attach Roof to Front Door Panel




Figure 4a




Figure 4b




Figure 4c

Cord hole is located in the crease



Figure 5




Figure 6

Heated Bed

Care & Instructions

Thank you for purchasing patented heated pad. When used correctly, your heated bed should provide years of hassle free warmth for your pet. It is intended for use indoors and outdoors and is perfect for garages, porches, barns and dog or cat houses. Your heated bed is designed for use with animals only.

WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock, or fire which could cause serious bodily injury.

USE INSTRUCTIONS

Read all instructions carefully. This is an electrical product, pay special care to IMPORTANT SAFEGUARDS.

- 1** Place directly on a hard, flat surface in the home or inside a doghouse or kennel. Area chosen should be a sheltered area out of direct rain or snow.
- 2** Plug into 110-120 volt AC outlet and allow 15 to 30 minutes for your heated bed to begin to warm and fully expand. The unit will feel slightly warm to the touch. The built-in thermostat will automatically regulate the temperature.
- 3** After initial warm-up, your heated bed will feel cooler to the touch. This is the intention for energy efficiency. When your pet lies on the bed, it will warm to a cozy, pet-pleasing temperature even in the coldest of weather.
- 4** Testing your heated bed. Place a blanket, pillow or other insulating object over part of your heated bed. After a few minutes, place your hand under the insulating object to experience the warmth your pet will enjoy.
- 5** To store your heated bed, unplug, clean, and store away when not in use.
- 6** **Save these instructions for your use.**

Limited One Year Warranty

Our warranty is as follows: Pet Products warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material and workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to Pet Products, with a **dated proof of purchase or original date receipt**.

IMPORTANT SAFEGUARDS

For Household Use Only*

**The heated pad is an electrical device and must only be operated inside an enclosure such as a porch, shed, barn, dog house, or cat house.*

When using electrical appliances, basic safety precautions should always be adhered to including the following:

READ ALL INSTRUCTIONS

- To protect against electrical hazards, **DO NOT** immerse cord, plug, or appliance in water or other liquid.
- **Close supervision is necessary** when used by or near children.
- **ALWAYS** unplug from outlet when not in use.
- **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions, or has been damaged in any way. **RETURN** all malfunctioning appliances to the Pet Products for examination.
- **DO NOT** use appliance for anything other than its intended use.
- **DO NOT PUNCTURE PLASTIC HOUSING FOR ANY REASON.**
- For use with 110-120 volt AC **ONLY**.
- **DO NOT** cover your heated bed with blankets or materials other than a fleece **COVER**. Other coverings may not allow heat to radiate properly and could cause pad failure.
- When used outside your home, this unit must be plugged into a properly grounded electrical outlet rated for outdoor use. If you do not have a properly grounded outlet, contact a certified electrician to have one installed.
- Always make sure the cord exits your pet's enclosure. Keep cord out of shelter.

Care Instructions:

Your patented heated pad may be cleaned with a damp cloth when unplugged. The unit may be plugged in when the pad is thoroughly dry.