

Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.


Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com


 SKU: PH04021 Assembly Instructions Laying out all the parts and hardware, identifying each part as shown may help you assemble the table.											
ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Table Top	1	D		Wood Base	1	G		Allen Wrench	1
B		Closed End X-shape Leg	4	E		Flat Washer	16	NOTE: The closed end X-shape legs must be attached to BOTH top and base.			
C		X-shape Leg	4	F		Bolts (6×25mm)	16				

STEP 1




Flip the table top A upside down, attach closed end X-shape legs B to the bottom of table top A in diagonal positions using bolts and washers as shown.

STEP 2




Insert X-shape legs C in the rest of the slots as shown above.

STEP 3



Tuck in the wood base D on top of the legs and tighten to the closed end X-shape legs B using bolts and flat washers as shown.

STEP 4



Finished product. Please make sure all the bolts are fully tightened before using this table.



WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 50Lbs. Do NOT overload.



COZAYH HOME