
ASSEMBLY & INSTALLATION INSTRUCTIONS

SS-55-55 Inch All Weather TV Hard Cover& Wall Mount



Two people required for installation

Our team is available 24/7 to help with any product questions. Contact us anytime!

Installation Tools (Not Included)

All Installations



Tape Measure

Pen/Pencil



Power Drill



Phillips Screwdriver



Bubble Level



Socket Wrench

Solid Concrete, Brick, Masonry Installation



Crescent Wrench



Hammer Drill



Hammer



2/5"(10mm) Masonry Drill Bit

Installation Video

Safety Caution

- Prior to installation of this product, the installation instructions should be read and completely understood to prevent personal injury and property damage. Keep these installation instructions in an easily accessible location for future reference.
- This mount and hard cover contains small parts which can act as a choking hazard if swallowed.
- CAUTION: The maximum TV load capacity is 100 lbs. (45 kg). Use with products exceeding the maximum load capacity may cause serious injury.
- The wall structure must be capable of supporting at least five times the maximum load capacity as indicated. If not, the wall must be reinforced.
- Do not mount on drywall or plywood alone.
- Do not install on a structure that is prone to vibration, movement or chance of impact. Failure to do so could result in damage to the display and/or damage to the mounting surface.
- Do not install near heater, fireplace, air conditioning or any other heat producing source. Failure to do so may result in damage to the display and/or the hard cover and could increase the risk of fire.
- Make sure no water or natural gas lines are present where the mount is to be installed. Cutting or drilling into water or natural gas lines could cause personal injury or property damage.
- Proper installation procedure by yourself or a qualified service technician, as outlined in the installation instructions, must be adhered to. Failure to do so could result in serious personal injury.
- If you don't understand these installation instructions, please consult an installation specialist.
- It is recommended that two people perform the installation. Injury and/or damage can result from dropping or mishandling the display or hard cover.


Supplied Parts & Hardware




Black Rubber Plug Hole
(1 PC)




Black Waterproof Tape
(1 PC)




Front—Left Part(1 PC)




Front—Right Part(1 PC)




Angle Brackets(2 PC)




Side—Left Part(1 PC)



Back—Left Part(1 PC)




Back—Right Part(1 PC)




Side—Right Part(1 PC)

E




M10x6x5mm
(9 PC)

F




W6x50mm
(9 PC)

L



M5x28mm
(10 PC)

M



M5 x20mm
(16 PC)

N





M5
(10 PC)




CHOKING HAZARD


Assembly & Installation Step









The wires must pass through this hole for the cover to be mounted on the wall !









Place TV hard cover Back at desired installation location
Mark in top left "key-hole" (ensure the mark is over a stud)






The TV mount and cover are secured to the wall together, and positioning can also be achieved via the cover.

Marked 4 locations on wall








Drill 4 holes at marked positions












Install 4 anchors into drilled holes, then install 4 hex lag screws through wall plate mounting holes and into anchors.









The bracket can be mounted on the wall first, then the TV assembled onto it. Alternatively, the TV can be mounted onto the bracket first, then the bracket mounted on the wall.

Ⓐ (M4x25)-4pcs

Ⓑ (M5x25)-4pcs

Ⓒ (M6x25)-4pcs

Ⓓ (M8x25)-4pcs

Ⓔ (M10x6x50)-5pcs

Ⓕ (W6x50)-5pcs

Ⓖ (M15x8x10)-4pcs


Ⓗ (M13x6x1.5)-4pcs

Ⓘ (M6)-4pcs


Ⓙ (M6x12)-4pcs


Ⓚ (M10)-1pcs


Connecting piece





TV stand












2.
1.
or
K



7.9"(200mm)
3.9"(100mm)
3.9"(100mm)
7.9"(200mm)
G



15.7"(400mm)
7.9"(200mm)
15.7"(400mm)
11.8"(300mm)
7.9"(200mm)
15.7"(400mm)
I
J


G
A+H / B+H / C / D


or
K


180°
180°
180°


+8°/-5°
± 4°
or
K


F

