

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.





- Dust and pick-up spills using a clean, non-colored, lint-free cloth.


Please look in carton for hardware packs and legs.

CLUB CHAIR



Parts List

Label	Picture	Description	QTY
A		Chair Base	1
B		Chair Backrest	1
C		Right Arm	1


D		Left Arm	1
E		Seat Cushion	1
F		Back Cushion	1
G		Wooden Leg	2

Hardware List

Label	Picture	Description	QTY
①		Bolt (M8x60mm)	11
②		Bolt (M6x60mm)	7
③		Washer	11
④		Spring Washer	11
⑤		Allen Wrench	1

Assembly Preparation

Before
Beginning
Assembly:



• Read instructions, cover to cover-



• Have 2 adults on hand for assembly-



• Do not assemble on flooring or carpet-




• Assemble on a clean non-marring surface (packing foam)-



• Save all packaging until finished-


Assembly Steps

Overview




This Club Chair has multiple parts and may require about 30 minutes to assemble. To give you an overview of the Club Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Take out the all parts and Small Box.
Open the Small Box to take out the Wooden Legs(G) and Hardware.
Place all the parts on a clean, non-marring surface.

Step 2




Open the Vacuum Bags to take out the Back Cushion(F).

Step 3




Place the Right Arm(C) and Left Arm(D) upside down on a clean floor. Place the Wooden Leg(G) at the bottom of the armrest and align them with the empty space, with the end labeled with “→” facing forward.
Use Allen Wrench (⑤) and 3 Bolts (②) to secure the Wooden Leg(G) to the bottom of the armrest.

Step 4



With assistance from your adult partner, hold up the Chair Backrest(B). Align the mounting brackets on both sides of the Chair Backrest(B) with those on the Left Arm(D) and Right Arm(C). Then slide Chair Backrest(B) downward by hand to make sure it locks into place as pictured.


Step 5



With assistance from your adult partner, align the mounting positions on the back and on both sides of the Chair Base(A) to the mounting positions on the Left Arm(D), Right Arm(C) and Chair Backrest(B).

Note: The bottom of the Chair Base(A) frame must be aligned with the bottom of the Backrest and Arms.

Step 6





Open the back non-woven cover under Chair Base(A).

Then attach using 8 Bolts(①), 8 Spring Washers(④) and 8 Washers(③) with Allen Wrench(⑤).

Please do not tighten the Bolts, just bolt them in half-way until all bolts are in, then tighten all the Bolts with the Allen Wrench(⑤).

Note: The bottom of the Chair Base(A) frame must be aligned with the bottom of the Backrest and Arms.

Step 7




Insert the 2 Bolts(①) half-way starting, then tighten the Bolts with the Allen Wrench(⑤).

Using the Allen Wrench(⑤) to secure Chair Base(A) to the bottom of Chair Backrest(B) with the 2 Bolts(①), 2 Spring Rings(④) and 2 Washers(③).


Insert the 2 Bolts(①) half-way starting one by one as pictured, then tighten the Bolts(①) with the Allen Wrench(⑤).

Step 8



Cover the bottom of the Chair Base (A) frame with non-woven fabric.

Step 9



Put the Back Cushion(F), Seat Cushion(E) on the Chair.

Now your Chair is ready for use.

This Chair can only be used on a flat, level surface.