
ASSEMBLY GUIDE & CARE INFORMATION

Nightstand

70900-NS



For the most up-to-date assembly instructions, scan the QR code below.

We continuously improve our guides based on customer feedback!

Most customers assemble under 60 minutes

Assembly is easiest with 2 people

Required tool (not provided)

#2 Phillips Screwdriver

Important Assembly & Safety Notes

1. **Do not assemble or use this product if any parts are missing, damaged, or broken.**
   Contact customer support for factory replacement parts before proceeding.

2. **Carefully check all packing materials before discarding the carton.**
   Small hardware may have come loose during shipment.

3. **Identify and count all parts and hardware before starting.**
   Compare each item with the parts and hardware list in the instructions.

4. **Follow the assembly steps exactly as shown.**
   Improper assembly may result in personal injury or property damage.

5. **Some parts may be heavy or have sharp edges.**
   Use caution when handling components.

6. **Secure all bolts firmly before use.**
   Do not use the product until all fasteners are fully tightened.

7. **Recheck and tighten all bolts every 90 days.**
   This helps maintain long-term stability and prevents loosening over time.

8. **Do not drag or push the furniture.**
   Always use two people to lift and reposition the furniture. Dragging may damage the legs or center support.

9. **Use floor protection on non-carpeted surfaces.**
   An area rug or furniture pads are recommended (not included).

10. **Do not use or store this product near open flames or flammable chemicals.**

11. **Keep these instructions for future reference and maintenance.**


Need a replacement part?

Please contact us through the website used for your purchase.
To help us resolve your request quickly, include:

- **Clear photos of the issue**
- **The part number and quantity needed**




IMPORTANT: Seller and Manufacturer disclaim all and any liability for property damage, personal injury, or loss, direct, indirect, or incidental, resulting from the incorrect assembly, inadequate maintenance, improper use, or neglect of this product.

Parts Check List







A	Side Panel Left	x1
B	Side Panel Right	x1
C	Top Panel	x1
D	Middle Panel	x1
E	Bottom Panel	x1
F	Back Panel	x1
G	Drawer Face	x1
H	Drawer Side Left	x1
I	Drawer Side Right	x1
J	Drawer Back	x1
K	Drawer Bottom	x1

Need a replacement screw?
Refer to the Hardware Check List below for size specifications.

L	Dowel	x8	M8 x 30mm	
M	Cam Bolt	x16	M6 x 24mm	
N	Cam Lock	x12	Ø15 x 12mm	
O	Cam Lock	x4	Ø15 x 9mm	
P	Screw	x6	M3.5 x 16mm	
Q	Screw	x4	M4 x 25mm	




Assembly Step 1


A	B	L
Side Panel Left	Side Panel Right	Dowel
x1 	x1 	x4  M8 x 30mm



• Insert L into A and B as shown.



Assembly Step 2


D Middle Panel	E Bottom Panel	L Dowel
x1 	x1 	x4  M8 x 30mm




• Insert L into D and E as shown.

Assembly Step 3





M Cam Bolt x8  M6 x 24mm	Phillips Screwdriver  Not Provided






• Insert M into A and B with a Phillips Screwdriver as shown.


Assembly Step 4

C Top Panel x1 	G Drawer Face x1 	M Cam Bolt x8  M6 x 24mm	Phillips Screwdriver  Not Provided




• Insert M into C and G using a Phillips Screwdriver as shown.


Assembly Step 5

N	Cam Lock	Phillips Screwdriver
x8		
	Ø15 x 12mm	Not Provided

Note: The holes for the cam lock found on D and E should be facing at the bottom





Note:
Align the opening or arrow on the cam lock with the opening on the part.




• Attach [D] and [E] to [A] and [B] with [N] using a Phillips Screwdriver as shown.

Assembly Step 6

N	Cam Lock	Phillips Screwdriver
x4		
	Ø15 x 12mm	Not Provided




Note:
Align the opening or arrow on the cam lock with the opening on the part.



• Attach C to A and B with N using a Phillips Screwdriver as shown.




Assembly Step 7


F Back Panel x1	P Screw x6 M3.5 x 16mm	Phillips Screwdriver Not Provided




• Attach F to Nightstand with P using a Phillips Screwdriver as shown.

Assembly Step 8


H Drawer Side Left x1 	I Drawer Side Right x1 	O Cam Lock x4  Ø15 x 9mm	Phillips Screwdriver  Not Provided




Note: Drawer glides must face outwards



Note:
Align the opening or arrow on the cam lock with the opening on the part.






• Attach G to H and I with O using a Phillips Screwdriver as shown.

Assembly Step 9




K Drawer Bottom


x1



• Slide K into H , I , and G as shown.

Assembly Step 10


J	Q	Phillips Screwdriver
Drawer Back	Screw	
x1 	x4 	
	M4 x 25mm	Not Provided



• Attach J to Assembled Drawer Box with Q using a Phillips Screwdriver as shown.

Assembly Step 11

NOTE: Pull the cabinet glides fully outward until they stop. Align the drawer glides with the cabinet glides and slide the drawer into place.




- Slide the Assembled Drawers into the glides as shown.

How to remove Drawer Box


Left Side


Pull the plastic clip **Up**.



Right Side

Push the plastic clip **Down**.






Note:
Press both clips at the same time while pulling the drawer outward.

FAQs FREQUENTLY ASKED QUESTIONS

WE ARE OPEN MONDAY TO FRIDAY TO ASSIST YOU AND WILL REPLY TO ANY OF YOUR MESSAGES WITHIN 24-48 HOURS. THE AVERAGE RESPONSE TIME IS WITHIN 24 HOURS. IF YOU ENCOUNTER AN ISSUE THAT IS NOT MENTIONED BELOW, PLEASE MESSAGE US IN OUR CONTACT PAGE BY VISITING WWW.DGCASA.COM


WHERE IS THE REST OF MY ORDER? THE PACKAGE I RECEIVED SAYS CARTON NO. 1 OF 3, CARTON NO. 3 OF 5, OR CARTON NO. 5 OF 6 ETC.

THE MARKETPLACE ONLY ALLOWS 1 TRACKING NUMBER TO BE UPLOADED IN THE SYSTEM. HOWEVER, THE PRODUCT IS SHIPPED IN MULTIPLE PACKAGES. YOU CAN CONFIRM THE NUMBER OF PACKAGES TO RECEIVE BY REFERRING TO THE CARTON NO. PRINTED ON THE PACKAGE THAT WAS DELIVERED TO YOU. FOR EXAMPLE, YOU RECEIVED 1 PACKAGE AND THE PACKAGE SHOWS CARTON NO. 1 OF 3, THEN CARTON NO. 2 OF 3 AND CARTON NO. 3 OF 3 IS IN TRANSIT TO YOU. THE REST OF THE PACKAGES CAN BE DELIVERED WITHIN THE SAME DAY AS THE FIRST PACKAGE OR WITHIN A FEW DAYS. ONCE THE ORDER IS SHIPPED CONFIRMED, OUR TEAM WILL SEND YOU A MESSAGE TO PROVIDE YOU WITH ALL THE TRACKING NUMBER THAT COMPLETES YOUR ORDER. IF YOU DID NOT RECEIVE THIS MESSAGE, PLEASE CHECK YOUR EMAIL'S SPAM FOLDER, OR LOG INTO THE MARKETPLACE ACCOUNT AND SEND US A MESSAGE.



MY ORDER IS DAMAGED, WHAT DO I DO?

CONTACT US ON OUR WEBSITE WWW.DGCASA.COM INCLUDE THE ORDER NUMBER AND ATTACH APPLICABLE IMAGES TO EXPEDITE THE CLAIM AND ENSURE OUR TEAM WILL PROVIDE THE APPROPRIATE RESOLUTION



I TRACKED THE PACKAGE AND IT SHOWS MY PACKAGE WAS DELIVERED, BUT I NEVER RECEIVED THE PACKAGE. I DOUBLE CHECKED WITH MY FAMILY MEMBER AND NEIGHBOR; THEY DO NOT HAVE THE PACKAGE. WHAT DO I DO?

CONTACT US ON OUR WEBSITE WWW.DGCASA.COM INCLUDE THE ORDER NUMBER AND LET US KNOW WHICH CARTON NUMBER OR TRACKING NUMBER YOU DID NOT RECEIVE, AND A TEAM MEMBER WILL REPLY TO YOUR MESSAGE ACCORDINGLY.



LOVE THE PRODUCT?

LOG INTO THE MARKETPLACE YOU MADE THE ORDER AND SHARE YOUR EXPERIENCE WITH THE PRODUCT AND WHAT YOU LIKE MOST ABOUT IT. ELEVATE THE PRODUCT REVIEW BY INCLUDING IMAGES OF THE PRODUCT TO SHARE WITH EVERYONE.

★★★★★