

ASSEMBLY INSTRUCTIONS FOR FLOOR LAMP

PLEASE READ AND SAVE THESE INSTRUCTIONS:

Be careful when unpacking the lamp since the wires are connected. If the wires are pulled out of their connectors, the lamp will not turn on.

1. Begin at the bottom of the lamp.
2. Screw the bottom lamp pole (B) onto the lamp base (A) clockwise.
3. Screw the middle lamp pole (C) into the bottom lamp pole (B) clockwise.
4. Screw the upper lamp pole (D) into the middle lamp pole (C) clockwise. You may need to pull any excess cord gently through the poles so that these two parts fit.
5. Put shade (E) onto the upper lamp pole (D).
6. Screw socket ring (F) onto the socket of upper lamp pole (D) till tight to secure the shade (E).
7. Item weight: 10.34LBS.

1. Use only with maximum of 1*100 watt incandescent bulbs (bulb not included).
2. BE SURE THE LAMP IS UNPLUGGED WHEN CHANGING THE LIGHT BULB.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

