

Care and Cleaning

- Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- Over time, the color of the fabric will fade under prolonged outdoor exposure. This is considered normal wear.
- For best color preservation, keep chairs indoors when not in use.

Ash & Willow

USE AND CARE GUIDE

APPLETON 3-PIECE ROUND PATIO BAR
HEIGHT DINING SET



Customer Service : 1-855-975-2287

Our customer service staff is available to help you. For any problem with your purchase, or to receive further information about this product, please call our toll-free number.

SAVE THIS MANUAL
Keep this manual and the original sales invoice in a safe, dry place for future reference.

Table of Contents

Table of Contents

Safety Information

Warranty

Pre-Assembly

Planning Assembly

Hardware Included

Chair Package Contents

Chair Assembly

Pre-Assembly

Table Package Contents

Table Assembly

Care and Cleaning

4

5

6

6

7

8

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1.

Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2.

Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

Warranty

Thank you for purchasing this product. These products have been made to demanding, high-quality, standards and are guaranteed for domestic use against manufacturing defects for a period of one (1) year following the date of purchase.

In case of any malfunction of your product (failure, missing part, etc.), please contact one of our service technicians at our toll-free service line at 1-855-975-2287 from 8 AM to 6 PM, Monday to Friday, Eastern time. You could also contact us at warrantycare@1800acs.com.

The product is guaranteed if used for normal residential purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair. Heavy-duty or daily professional/commercial usage is not covered by the warranty. Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.


Table Assembly

- 1

Attach the table leg to the table top

□ Attach the table leg (I) to the table top (G) using M6 bolts (AA) and washers (BB)

NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (DD) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (CC) after final assembly finished.




- 2

Attach the leg connector to the table leg


□ Attach the leg connector (H) to the table leg (I) using M6 bolts (AA) and washers (BB).

NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (DD) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (CC) after final assembly finished.



- 3

Assembly complete.




Pre-Assembly

TABLE PACKAGE CONTENTS



IMPORTANT: Do not fully tighten bolts until all pieces are loosely assembled.



Part	Description	Quantity
G	Table top	1
H	Leg connector	1
I	Table leg	4

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	M6x20 bolt	40
BB	Washer	40
CC	Bolt cap	40
DD	Allen driver	1

Pre-Assembly

CHAIR PACKAGE CONTENTS



IMPORTANT: Do not fully tighten bolts until all pieces are loosely assembled.



Part	Description	Quantity
A	Seat panel	2
B	Seat cushion	2
C	Right chair leg	2
D	Left chair leg	2
E	Long support bar	2
F	Short support bar	2


Chair Assembly

- 1
- Attach the chair leg to the seat panel
- ☐

Attach the left (D) and right (C) chair leg to the seat panel (A) using M6 bolts (AA) and washers (BB).



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (DD) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (CC) after final assembly finished.




- 2
- Attach the support bar to the chair leg
- ☐

Attach the support bar (E and F) to the left (D) and right (C) chair leg using M6 bolts (AA) and washers (BB).



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (DD) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (CC) after final assembly finished.



- 3
- Add seat cushion
- ☐

Add the seat cushion (B) to the chair.

