

WOODEN CRATE DISASSEMBLY GUIDE

1. Wear work gloves before dismantling the crate.
2. Straighten and flatten the bottom of the crate.
3. Knock all of the retaining clasps on the bottom.
4. Open the bottom clasp fully. Do not shake the crate sideways, and lift it evenly when clearing the bath.
5. Complete the disassembly and remove the tub.

PLEASE BE CAREFUL WHEN DISMANTLING THE CRATE
Por favor, tenga mucho cuidado al desmontar la caja.






WARNING!

1 = 2 = 3 = 4 = N

Note:
1) To prevent damage, please ensure the box remains flat during movement.


2) Remove the crate by applying even upward pressure on all four sides.




GUÍA DE DESMONTAJE DE CAJAS DE MADERA

1. Utilice guantes de trabajo antes de desmontar la caja.
2. Enderece y aplánela base de la caja.
3. Golpee todas las grapas de fijación de la base.
4. Abra del todo la grapa inferior. No sacuda la caja de lado a lado y levántela parejo al retirarla.
5. Complete el desmontaje y retire la bañera.

POR FAVOR, TENGA MUCHO CUIDADO AL DESMONTAR LA CAJA
Please be careful when dismantling the crate.





¡PRECAUCIÓN!

1 = 2 = 3 = 4 = N

Nota:
1) Para evitar daños, asegúrese de que la caja permanezca plana durante el movimiento.

2) Retire la caja aplicando presión uniforme hacia arriba en los cuatro lados.

