
Power Reclining Sofa

ASSEMBLY INSTRUCTIONS



IMPORTANT SAFETY INSTRUCTIONS:

- Read all instructions carefully before unpacking assembly parts. Sharp, exposed staple tips can cause injury. For your protection, please remove any exposed staples used in packing.
- For your safety, assembly by two or more adults is recommended.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural intergrity of the item.
- Keep instructions for future use.
- Intended for residential use only.
- Keep small parts and hardware out of the reach of children.



PRE-ASSEMBLY INSTRUCTIONS:

- Remove all parts and hardware from the box and place them on a carpeted or scratch-free work surface.
- To avoid accidentally discarding small parts or hardware, please do not dispose of any contents until assembly is complete.
- Prior to starting assembly, use the parts and hardware lists to identify and separate each of the pieces included.
- Do not over-tighten screws or bolts.

TABLE OF CONTENTS

Parts List	**Page 3**
Assembly Instructions	**Pages 4-6**
Care & Maintenance & Warnings	**Pages 7**

PARTS LIST


PART #	PICTURE	PART DISCRIPTION	LOCATION	QTY
A		Back Cushion	Directly in the carton	2
B		Seat Base	Directly in the carton	1
C		AC Power Cord	With red guide tape and you can find it in the carton	1

Thank you for your purchase. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts and hardware lists.

STEPS

Step 1: Slide the KD back into the steel mechanism posts in the base of of the furniture.


Step 2: Press both sides of the back firmly into place.The back automatically locks into place.



STEPS


Step 3: Zipped back cushion and seat cushion together.






STEPS

Step 4: Attach the outside back along the bottom rear of the base frame with pre-attached velcro.



STEPS

Step 5: Connect the AC power cord to the main switch behind the arm, and finally connect the cord with a power source.



CARE & MAINTENANCE

Fabric Care Tips

- Be sure to vacuum on a weekly basis so dust and dirt do not settle into the fabric.
- Wrinkles in the fabric are a natural part of normal wear
- Fabric can fade when exposed to direct sunlight over a long period of time.
- To minimize fading, avoid placing your furniture in direct sunlight.
- Avoid cleaners which use chemical products. Many of these are harsh and not safe for use on upholstery.
- Stress to the fabric may result in tears and when stretched, upholstery may not completely return to its original shape.
- Avoid sitting in one area and use the seating areas evenly for even wear.
- Fabric is not resistant to animals. Allowing pets on your upholstered furniture is not recommended.
- If pillow cushions are sewn to the frame, any pulling or tugging may result in a tear.

WARNING

- Do not use this product unless all screws and bolts are securely tightened.
- Check that all screws and bolts are secure every three months or as needed
- Dispose of packing material properly. Do not use plastic cover as head covering as it may cause suffocation.
- Do not use this product as a stepladder.
- Use this product for intended purpose only.
- Intended for residential use only.