


# Assembly Instructions



## ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY



DIFFICULT

## Tools Required For Assembly:

Allen Wrench



(Included)

Philip Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


## Parts List




#1 x 1pc  
Headboard




#2 x 1pc  
Footboard




#3 x 2pcs  
Rail (L&R)




#4 x 1pc  
Headboard Panel




#5 x 2pcs  
Ear Panel (L&R)




#6 x 2pcs  
Support Bar



#7 x 2pcs  
Headboard Support Rail




#8 x 11pcs  
Slats




#9 x 3pcs  
Slats Whit Hole


## Hardware List




#A x 1pc  
Allen Wrench M4




#B x 10pcs  
Bolt Ø1/4" x 1-1/2"




#C x 8pcs  
Bolt Ø1/4" x 3-1/2"




#D x 10pcs  
Bolt Ø1/4" x 2-3/8"




#E x 4pcs  
Bolt Ø1/4" x 1-3/16"




#F x 32pcs  
Lock Washer Ø1/4"




#G x 14pcs  
Flat Washer Ø1/4" x 19mm



#H x 18pcs  
Flat Washer Ø1/4" x 25mm




#I x 2pcs  
Anti Slip Sheet



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


## Parts List




#10 x 2pcs  
Center Rail



#11 x 2pcs  
Footboard Leg




#12 x 6pcs  
Slat Support Leg 285x30x30mm




#13 x 2pcs  
Center Rail Support


## Hardware List




#J x 4pcs  
Screw M3 x 5/8"




#K x 4pcs  
Screw M4 x 1"



#L x 30pcs  
Screw M4 x 1-3/16"



#M x 6pcs  
Screw M4 x 1-3/4"








#1

Align HB support rails (#7) to the headboard (#1), then secure by using bolts (#B) with washers (#F,H).


#B x 4pcs  
#F x 4pcs  
#H x 4pcs



#2

Align headboard (#1) to the ear panels (#5R/L), then secure by using bolts (#B) with washers (#F,H).

#B x 6pcs  
#F x 6pcs  
#H x 6pcs






#3

Align center rail supports (#13) to the footboard (#2), then secure by using bolts (#D) with washers (#F,G).


#D x 4pcs  
#F x 4pcs  
#G x 4pcs



#4

Align legs (#11) with washer (#I) to the footboard (#2), then secure by using screws (#K)


#I x 2pcs  
#K x 2pcs






Align side rails (#3R/L) to the footboard (#2), then secure by using bolts (#E) with washers (#F,G).

#E x 4pcs  
#F x 4pcs  
#G x 4pcs



Secure the legs (#11) to the side rails (#3R/L) by using screws (#K).


#K x 2pcs






Align headboard ears (#5R/L) to side rails (#3R/L), then secure by using bolts (#C) with washers (#F,H).


#C x 4pcs  
#F x 4pcs  
#H x 4pcs



#J x 4pcs



Align HB panel (#4) to the headboard, then secure by using screws (#J).









Align support bars (#6) to the bottom of the side rails (#3R/L), then secure by using screws (#M).  
Secure side rails (#3R/L) to HB ears (#5R/L) by using bolts (#C) with washers (#F,H).

#C x 4pcs  
#F x 4pcs  
#H x 4pcs  
#M x 6pcs



#D x 6pcs  
#F x 6pcs  
#G x 6pcs

Align center rails (#10) to the slats (#9) and  
slat support legs (#12), then secure  
by using bolts (#D) with washers (#F,G).






#11

#L x 8pcs

Secure slats (#9) to side rails (#3R/L) by using screws (#L).



#12

#L x 22pcs

Align slats (#8) to the side rails (#3R/L), then secure by using screws (#L).

