ROYALCRAFT

Transforming houses into homes (English & Español)

ZSC028



INSTRUCTION MANUAL

Contact Information

Question about your product? We're here to help. Contact us by:

707-392-8405

support@royalcraft.store

www.royalcraft.store

Orders FAQ | **Product Assembly** | **Product Inquiry** | **Chat Support** | **Returns & Refunds**

If you have any problems, please send your order number and photos to us.
We will contact you within 24 hours and provide you with a satisfactory solution.

NOTICE **Please retain these instructions for future reference.**

- Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.
- Identify each component and refer to the provided assembly diagram or step-by-step instructions.
- Assemble the furniture in the order specified to ensure proper alignment and fit.
- Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.
- If any difficulties arise during assembly.Consult the troubleshooting section or contact our customer support.


Watch&Learn


For assembly videos and maintain tips,


you can visit royalcraft.store

or scan the QR.


ASSEMBLY INSTRUCTIONS









PARTS LIST


A
Front Panel

1 PC


B
Left Side Panel

1 PC


C
Side Panel Left and Right Support Bar

2 PCS


D
Left Rear Leg


1 PC


E
Left Front Leg

1 PC


F
Back Panel

1 PC


G
Crossbar Under the Drawer

2 PCS


H
Rear Bottom Pull Bar

1 PC


I
Rear Crossbar

1 PC


J
Front Bottom Pull Bar

1 PC


K
Front Crossbar

1 PC


L
Right Side Panel

1 PC


M
Right Rear Leg

1 PC


N
Right Front Leg

1 PC


O
Drawer Back Panel

3 PCS

P
Left Drawer Side

3 PCS

Q
Right Drawer Side

3 PCS

R
Drawer Bottom Support Bar

3 PCS


S
Drawer Front

3 PCS

T
Drawer Bottom Panel

3 PCS

HARDWARE LIST


01
Ø15X9.5mm
Cam Lock


57+3 PCS


02
Ø6.5X35mm
Cam Bolt

57+3 PCS

03
Ø6X30mm
Wooden Dowel

14+2 PCS

04
Ø3.5X12mm
Screw

36+3 PCS

05
Ø4X20mm
Screw

6+1 PCS

06
Ø4X35mm
Screw

21+2 PCS

07
31X31X26mm
Handle

3 PCS

08
M4X8mm
Screw

3+1 PCS

9CL
300mm
Left Cabinet Slide Rail

3 PCS

9CR
300mm
Right Cabinet Slide Rail

3 PCS

9DL
300mm
Left Drawer Slide Rail

3 PCS

9DR
300mm
Right Drawer Slide Rail

3 PCS

10
Back Panel Buckle
Ø3X14mm
Screw

12+2 PCS

11
Ø21mm
Screw Hole Sticker

57+3 PCS

12
Anti-Tipping Device


2 PCS


⚠ If you are missing any parts, please provide your order number and circle the part number. Send us a photo of this, and we will provide you with a satisfactory solution. Thank you.


STEP 1


Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.
















STEP 2


Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.



Ø15X9.5mm Cam Lock	Ø6X30mm Wooden Dowel	Ø4X35mm Screw	Ø21mm Screw Hole Sticker
① X6	③ X4	⑥ X3	⑪ X6









STEP 3

Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.






Ø6.5X35mm

Cam Bolt


②	X10



Ø3.5X12mm

Screw


④	X9





300mm

Right Cabinet Slide Rail

9CR	X3









STEP 4


Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.




Ø15X9.5mm Cam Lock	Ø6.5X35mm Cam Bolt	Ø6X30mm Wooden Dowel	Ø21mm Screw Hole Sticker
① X13	② X3	③ X2	⑪ X13












STEP 5


Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.













STEP 6


Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.




Ø15X9.5mm Cam Lock	Ø6.5X35mm Cam Bolt	Ø6X30mm Wooden Dowel	Ø21mm Screw Hole Sticker
① X6	② X4	③ X4	⑪ X6










STEP 7

Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.





Ø6.5X35mm Cam Bolt	
②	X10


Ø3.5X12mm Screw	
④	X9

300mm Right Cabinet Slide Rail	
9CL	X3










STEP 8

Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.





Ø15X9.5mm

Cam Lock


1	X10




Ø21mm

Screw Hole Sticker

11	X10






STEP 9

Please tighten the screws after completing all installation.


Por favor, apriete los tornillos después de instalar todo.



STEP 10

Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.





Ø15X9.5mm

Cam Lock

①	X4



Ø6X30mm

Wooden Dowel


③	X4




Ø21mm

Screw Hole Sticker

⑪	X4







STEP 11


Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.




Ø15X9.5mm Cam Lock	Ø6.5X35mm Cam Bolt	Ø4X35mm Screw	Ø21mm Screw Hole Sticker
① X18	② X18	⑥ X18	⑪ X18







1 2


4 3








X3




STEP 12

Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.





Ø3.5X12mm
Screw

4	X18




300mm
Left Drawer Slide Rail

9DL	X3



300mm
Right Drawer Slide Rail

9DR	X3





X3


STEP 13


Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.












STEP 14


Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.










STEP 15

Please tighten the screws after completing all installation.

Por favor, apriete los tornillos después de instalar todo.




NOTE: The provided tipping restraint hardware is designed for use with wooden stud wall construction and should be affixed to a wall stud. If your wall construction differs, you may require alternative anchor hardware. Please consult your local hardware store for guidance. It's crucial to be aware that young children are at risk of serious injury from furniture tipping over, so you must install the provided tipping restraint hardware with the unit to prevent accidents or damage. These restraints serve as a deterrent and are not a substitute for responsible adult supervision. It's important to note that the tipping restraints are not designed for earthquake safety. If you wish to enhance security for earthquake situations, separate earthquake restraints must be acquired and installed.


We have provided a set of tipping restraint hardware for this unit, and it is essential to install this hardware to prevent accidents or injuries that may occur if the unit tips over. When correctly installed, this restraint can offer protection against unexpected tipping caused by minor vibrations, impacts, or climbing. We highly recommend attaching this hardware to a wall stud and securing it to your unit for safety.




Install The Anti-Tipping Device




1. Mark the wall for reference.




2. Drill two Ø6 holes in the wall.




3. Insert two anchors into the holes.



4. Secure the device to the wall using the provided long screws.



5. Position the cabinet near the wall, aligning the two bases. Attach a nylon tie to ensure a snug fit.



MAINTENANCE AND CARE

Prevent Moisture Damage:

Safeguard your laminate furniture by keeping it in a dry environment. Store the furniture away from damp areas and water sources.

Sunlight Shielding:

Shield your laminate furniture from direct sunlight to prevent color fading and surface deterioration. Consider using curtains or blinds for protection, especially if direct sunlight exposure is unavoidable.

Regular Care:

Maintain your laminate furniture's appearance by gently wiping surfaces with a damp cloth. Avoid using overly wet cloths or abrasive cleaning tools.

Avoid Scratches:

Protect the furniture surface from scratches by refraining from placing sharp or hard objects on it. When moving the furniture, be cautious not to scrape the legs against the floor.

Proper Weight Distribution:

Prevent structural damage by placing heavy objects on stable support surfaces rather than directly on the laminate furniture's surface. This simple step can prolong the life of your furniture.

Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improrer assembly, or failure to adhere to the care and maintenance guidelines provided.

WARRANTY CLAIM PROCESS

To initiate a return on Amazon, please follow these steps:

1. Log into your Amazon account and go to the "Your Orders" section.
2. Locate the order containing the item you wish to return.
3. Contact our customer service for assistance in obtaining a prepaid return label.
4. Once you receive the return label, securely affix it to the package.
5. You can then choose to drop off the package at a designated carrier location or arrange for a pickup.
6. After we receive and inspect the returned product, we will initiate the refund process.
7. The refund will be credited back to the original payment method used during the purchase.
8. Typically, refunds are processed within 3-5 business days.

MANTENIMIENTO Y CUIDADO

Evite daños por humedad:
Proteja sus muebles laminados manteniéndolos en un ambiente seco. Guarde los muebles lejos de zonas húmedas y fuentes de agua.

Protéjalos de la luz solar:
Proteja sus muebles laminados de la luz solar directa para evitar la pérdida de color y el deterioro de la superficie. Considere el uso de cortinas o persianas como protección, especialmente si la exposición directa a la luz solar es inevitable.

Cuidado regular:
Mantenga el aspecto de sus muebles laminados limpiando suavemente las superficies con un paño húmedo. Evite utilizar paños demasiado húmedos o herramientas de limpieza abrasivas.

Evite los arañazos:
Proteja la superficie del mueble de arañazos evitando colocar objetos afilados o duros sobre ella. Al mover el mueble, tenga cuidado de no raspar las patas contra el suelo.

Distribución adecuada del peso:
Evite daños estructurales colocando objetos pesados sobre superficies de apoyo estables en lugar de directamente sobre la superficie del mueble laminado. Este sencillo paso puede prolongar la vida de sus muebles.

INFORMACIÓN SOBRE LAGARANTÍA

Cobertura de la garantía: Nuestra garantía proporciona protección contra defectos de fabricación en materiales y mano de obra durante un período determinado a partir de la fecha de compra, como se indica en la documentación de garantía adjunta.

Exclusiones: La garantía no cubre los daños resultantes de uso indebido, negligencia, accidentes, desgaste normal, reparaciones o modificaciones no autorizadas, montaje incorrecto o incumplimiento de las directrices de cuidado y mantenimiento proporcionadas. Las directrices de cuidado y mantenimiento proporcionadas.

PROCESO DE RECLAMACIÓN DE LA GARANTÍA

Para iniciar una devolución en Amazon, siga estos pasos:

1. Accede a tu cuenta de Amazon y ve a la sección "Tus pedidos".
2. Localiza el pedido que contiene el artículo que deseas devolver.
3. Ponte en contacto con nuestro servicio de atención al cliente para que te ayuden a obtener una etiqueta de devolución prepagada.
4. Una vez que reciba la etiqueta de devolución, fíjela firmemente al paquete.
5. A continuación, puede optar por depositar el paquete en el lugar designado por el transportista o solicitar que lo recojan.
6. Después de que recibamos e inspeccionemos el producto devuelto, iniciaremos el proceso de reembolso.
7. El reembolso se abonará de nuevo al método de pago original utiliza-do durante la compra.
8. Normalmente, los reembolsos se procesan en un plazo de 3 a 5 días laborables.

★ SHARE YOUR SPACE ★

We love to see where our furniture ends up-
snap a pic and tag if on Instagram or Face
-book for your chance to be featured on our
social channels and WIN A PRIZE

LEARN MORE

★ COMPARTE SU ESPACIO ★

Nos encanta ver dónde acaban sus muebles.
Tome una foto y etiquétela en Instagram o
Facebook para tener la oportunidad de apa-
recer en nuestros canales sociales y GANAR
UN PREMIO.

@royalcrafthome

ROYALCRAFT

707-392-8405

support@royalcraft.store

www.royalcraft.store

Royalcrafthome

If you have any problems, please send your order number and photos to us.
We will contact you within 24 hours and provide you with a satisfactory solution.

0920 V1