















ASSEMBLY INSTRUCTIONS
INSTRUCTIONS D'ASSEMBLAGE




TV STAND-60"L GREY WOOD/BLACK DOORS
MEUBLE TV-60"L BOIS GRIS/PORTES NOIRS




						
	ø15x9mm	4x40mm	6x30mm		6x65mm	
A 8PCS	B 8PCS	C 20PCS	D 28PCS	E 4PCS	F 4PCS	G 4PCS
						
			3.5x14mm			
H 1PC	I 4PCS	J 2PCS	K 16PCS	L 4PCS		


step 1




step 2




step 3




step 4




step 5




step 6




step 7



step 8



step 9



step 10

