
Installation Instructions




Parts Included

A*1




Backrest

B*1




Seat

C*1



Leg Rest

D*1




Headrest

E*1




Footrest

F1*1 F2*1 F3*1 F4*1 G*1 H*4 J*1 I*4 J2*1




Wrench Screws

K*1




Base

L*1




Pump

M*1



Step Pedal

1 Install the base and pump




1-1. Secure the pump cover with J.

1-2. Secure the pump and base with H and I.


2 Install the step pedal

2-1. Insert K into the pump and tighten the screw.



D2*1 Wrench M Step Pedal

! Pay attention to the orientation of M.




3 Install the seat to the pump


Two person are recommended to complete this step.

3-1. One person lifts the seat.

3-2. The other person adjusts the position of the seat from below.

3-3. Insert the seat onto the pump.






4 Install the leg rest


D2*1	D3*1
	

4-1. Remove the screws pre-installed on both sides of the seat.

4-2. Align the leg rest and the screw holes on both sides of the seat.


4-3. Reinsert and tighten the screws removed in the previous step.






4-4. Remove the two screws pre-installed behind the leg rest.


4-5. Align the screw holes between the two connecting irons and the leg rest, insert, and tighten the screws.






5 5. Install the footrest.


5-1. Remove the screws pre-installed on both sides of the footrest.




5-2. Align the screw holes on the footrest and both sides of the leg rest, insert, and tighten the screws



6 Install the backrest


F2*1	A*1	D*1
		
Wrench	Backrest	Headrest

6-1. Remove the pre-installed screws on the backrest.



6-2. Place the backrest onto the chair, align the screw holes, and insert the screws (do not tighten the screws yet).

6-3. Adjust the backrest angle, ensure it is centered on the chair, and then tighten the three screws.



Chair Operation Guide


1

Locking or Unlocking the Chair's Swivel Function

This chair has a locking feature.

1-1. Unlocking the Chair

Press down the step pedal while rotating the chair; at this point, the chair can swivel.




rotating unlocked

2 Adjusting the Chair Height

2-1. Raising the Chair

Continuously press the step pedal halfway down, and the chair will rise.



2-2. Lowering the Chair

Press the step pedal all the way down and hold it, and the chair will lower.


3

Locking or Unlocking the Chair's Swivel Function

This chair has a locking feature.


3-1. Locking the Chair

Lift the step pedal upwards, and the internal oil pump will lock, preventing the chair from rotating.



rotating locked

Correct Way to Leave the Chair to Avoid Tipping



Incorrect Example:

There is a significant distance between the support rod and the ground, stepping on the foot pedal at this time may cause the chair to tip forward.

Correct Example:

Lower the chair to the lowest position, the support rod will close to the ground, you can safely step on the foot pedal and leave the chair.

Trouble and Solution

NO.	Trouble	Potential Issues	Solution
1	The pump is not working.	The pump's lift function is not working properly.	Please refer to section 2 of the operation guide to check if the operation is correct.
2		Cannot swivel.	Please refer to section 3 of the operation guide to check if the operation is correct. If the chair still has difficulty rotating, please repeat lifting the foot pedal and then pressing it down while rotating the chair several times. This should make the chair easier to rotate.
3	The pump is making unusual noises.	There is air inside the pump.	Because it's brand new, there may be some air inside the pump. Please repeatedly lift and lower the chair to expel the air.
4	The chair is wobbling.	Loose connection between the pump and the base.	Please check the screws underneath the base and tighten them again.
5	Missing screws.	Some screws are pre-installed.	Most screws are pre-installed on the chair's components. Please check again to see if there are screws in the screw holes on the chair's components.
6	Missing parts.	The chair is shipped in two packages.	If your chair is shipped in two separate packages, we will send you the tracking numbers for both packages via Amazon after the chair has been shipped. Please keep an eye out for them. The two packages may not arrive simultaneously.
7	Damaged	The chair leather, metal, and other accessories are damaged.	If you find any damage to the chair after receiving it, please do not rush to return it. Please contact us and provide pictures of the damage in your message so that we can quickly identify the required parts. We will promptly send you the replacement parts.
8	Other issues	Contact Us	In order for us to better understand and resolve the issue quickly, please provide relevant pictures or videos related to the problem in your email.

WARNING:

ANY PACKING BAGS OF THIS PRODUCT ARE NOT TOYS. TO AVOID THE DANGER OF SUFFOCATION, KEEP AWAY FROM BABIES AND CHILDREN. DO NOT USE IN CRIBS OR BEDS.