SICOTAS

SC113A1CLTY0670



Made In China

SICOTAS

Assembly Instructions

Before beginning the assembly process, please read and save these instructions for reference. Following these guidelines will ensure a smooth and successful assembly of your product.

1. Part Identification:

Carefully separate and identify all the parts included in your package. Confirm that you have all the components listed in the instruction manual. This step will help you avoid any missing or misplaced parts during assembly.

2. Work Surface:

To prevent any scratches or damage to the product, assemble it on a soft mat or a similar protective surface. This will provide a cushioned area for the components and protect the surfaces from unwanted marks.

3. Step-by-Step Assembly:

Follow the assembly instructions provided, proceeding one step at a time. Take care to understand each step properly before proceeding to the next one. This sequential approach ensures that the assembly is done correctly and minimizes the chance of errors.

4. Proper Screw Seating:

When attaching screws and nuts, it is essential not to fully tighten them until all screws are correctly seated. By partially tightening each screw and nut initially, you can ensure that they are aligned properly and fit securely before final tightening.

5. Avoid Over-Tightening:

While each screw and nut should be tightened correctly, it is crucial not to over-tighten them. Over-tightening can cause damage to the product or compromise its structural integrity. Use the appropriate amount of force to secure the components without excessive tightening.

If you encounter any questions or problems during the assembly process, please do not hesitate to contact us. We strive to provide excellent customer support and will respond to your inquiries within 24 hours. Our team will offer you a suitable solution to address any concerns you may have.

SICOTAS Customer Help Center:

Service@sicotas.com

www.sicotas.com

833-742-6827

Official Website: WhatsApp: YouTube: Ins: Tik Tok:

Parts List



Hardware List

A *14 ϕ15x9.5mm	B *14 ϕ6x24mm	C *24 ϕ8x30mm	D *4 ϕ4x50mm	E *2	F *2 M3x13mm	G *16 ϕ4x14mm	H *12 ϕ3x16mm
I *8	J *10 ϕ4x15mm	K *10	L *4	M *4 ϕ35mm	N *2	O *2 ϕ4x35mm	P *2
Q *1	R *8 ϕ4x30mm						

Code	Description	Quantity
A	ϕ15x9.5mm Cam lock	14+2
B	ϕ6x24mm Cam bolt	14+2
C	ϕ8x30mm Wood dowel	24+2
D	ϕ4x50mm screw	4+2
E	Bouncer	2
F	ϕ3x13mm Screw	2
G	ϕ4x14mm Screw	16+2
H	ϕ3x16mm Screw	12+2
I	Shelf support	8+2
J	ϕ4*15MM Screw	10+2

Code	Description	Quantity
K	Backboard clip	10+2
L	Foot pad	4+1
M	Hinges	4
N	Wall bracket	2
O	ϕ4x35mm Screw	2
P	Wall anchor	2
Q	Door stop	1
R	ϕ4x30mm Screw	8+2

Step 1





B *4	E *2	N *2	J *10

Step 2





B *10	C *16
	

Step 3





Step 4





Step 5



C *8	R *8

Step 6





Step 7







H *2	Q *1

Step 8





D *4	L *4

Step 9



Step 10









Step 11



Step 12



Step 13





F *2	G *8	M *4

Step 14



G *8

Cabinet Door Adjustment Instructions

Height adjustment:

a) Locate the height adjustment screws on the hinge.

b) Use the Phillips screwdriver to either tighten or loosen the screws to raise or lower the cabinet door as desired.







Side-to-side adjustment:

a) If the cabinet door needs to be moved closer to or away from the cabinet frame, locate the side - to-side adjustment screws on the hinge.

b) Use the Phillips screwdriver to adjust these screws and gradually move the door in the desired direction.







Depth adjustment (if applicable):

a) Check if the cabinet door needs to be brought closer to or further away from the cabinet frame.

b) For-depth adjustment, locate the depth adjustment screws on the hinge.

c) Use the Phillips screwdriver to turn these screws clockwise or counterclockwise accordingly.







Step 15





Step 16