









# Assembly Instructions

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)

PARTS LIST:				HARDWARE LIST				
NO.	Description	Sketch	Quality	NO.	Sketch	Description	Side	Quality
A	Top		1pc	1		Blots	Ø5/16"*1 3/8"	8pcs
				2		Flast washer	Ø5/16"*1/2"	8pcs
B	Legs		2pcs	3		Look washer	Ø5/16"*3/4"	8pcs
				4		Allen wrench	M5*65L	1pc
C	Support Legs		1pc					



Tips: for a aligning doors:

Tip A: Sometimes the doors will not line up because of an uneven floor surface the furniture reats on. In that case, try adjusting the levelers found on the bottom of each foot to aid in corecting.

