




Wall Mounted Bathroom Cabinet with Towel Bar



Save these instructions.



A buddy is helpful for assembly.



Level of difficulty: Intermediate.



40 minutes



Phillips Screwdriver needed. Not included

Thank You for your Purchase

- This user manual contains important and useful information to accompany your purchase. This product is intended for indoor, household use only. Failure to follow the instructions outlined may result in personal injury or damage to the product which the manufacturer or vendor cannot be held responsible.
- Please ensure you keep the instruction manual in a safe place so you can refer to the instructions at any time in the future. Adult assembly required. During assembly, children should always be kept away due to possible risk of injury. Please use caution and care when lifting the product to avoid personal injury and/or damage. Please ensure that you have enough space and people to assemble your product safely. Do not stand on the product or use as a stepladder.
- For ease and speed of assembly, we recommend that you identify all parts required for that step before begin. All items are to be assembled near the area which they will be placed in use to avoid moving the product unnecessary once assembled.
- For the protection of your furniture, we recommend that the product be assembled on a protected surface to prevent any damage. During assembly please take care not to over-tighten any fittings, as this may damage the product. Always place the product on a flat and stable surface.

Safety Precautions









- **READ ALL INSTRUCTIONS BEFORE ASSEMBLING PRODUCT FOR INDOOR, RESIDENTIAL USE ONLY ADULT ASSEMBLY REQUIRED**
- **DO NOT** throw away packaging material before you finish assembling to ensure that parts are not thrown out by mistake
- **DO NOT** use accessories or attachments that are not provided or recommended by manufacturer.
- **NEVER** force any parts or hardware into place when assembling.
- **KEEP CHILDREN** well away from plastic bags and packing materials this item was shipped in.
- **SAVE** these instructions for future reference.
- **DO** anchor product on the wall with at least 1 anchor in contact with stud
- **DO NOT** place items, such as toys and remote controls on top of dressers, TVs and other large furniture. Also, make sure that all cords are out of the reach of children.









Save these
instructions.

Parts

Removing your Cabinet from the carton is best accomplished with help from a friend. Gently lay the carton on its side, preferably on a carpeted floor. Remove all packaging material and set aside. Make sure all parts and hardware are present before assembly. 2 person assembly is recommended.




PART	NAME	QTY	PART IMAGE
1	Left panel	1	
2	Right panel	1	
3	Right door	1	
4	Left door	1	
5	Top shelf	1	
6	Adjustable shelf	1	



PART	NAME	QTY	PART IMAGE
7	Lower cross bar	1	
8	Towel bar	1	
9	Upper back panel	1	
10	Lower back panel	1	
11	Lower shelf	1	
12	Bottom shelf	1	
13	Upper cross bar	1	



Save these instructions.

Hardware

HARDWARE	NAME	QTY	HARDWARE IMAGE
A	Cam bolt	18	
B	Cam lock	18	
C	Wood dowel	8	
D	Knob	2	
E	Magnet	1	
F	Screw M4x40mm	2	
G	Magnet Plate	2	


HARDWARE	NAME	QTY	HARDWARE IMAGE
H	Screw M3x12mm	20	
I	Wall Anchor	2	
J	Screw M3.5x18mm	2	
K	Metal hinge	4	
L	Shelf holder	4	
M	Screw hole cover	16	

Safety Precautions

Step 1




Risk of damage or injury. Cam Lock and Bolt system is a multi steps process. Please follow these directions closely. Hidden Cams must be completely tightened. Hidden Cams that are not completely tightened may loosen and parts may separate.




Gently screw Cam Bolt into the threaded anchor at the specified location. Tighten with a Phillips screwdriver until threads are not visible

Step 2



Gently insert Cam Lock in the pre-drill holes at the specified location with arrow pointing toward the receiving hole or toward the closest edge. Use a Phillips screwdriver to turn as needed. Make sure Cam Lock is flushed with the board

Step 3




Insert Cam Bolt into the predrilled hole on the side of the Cam Lock board. Turn Cam Lock to engage the locking system



Save these instructions.

Parts




Save these
instructions.

Assembly Instructions

ASSEMBLY TIPS:

1. Remove hardware from box and make sure all your parts are there, prior to assembly.
2. To avoid damage to parts and components, layout and assembly should be done on a flat surface.
3. Please check and distinguish each part before assembly.
4. This product is intended for home use only and not intended for commercial establishments.
5. **DO NOT** attempt to repair or modify parts that are broken or defective. Please contact customer service

Specifications



Maximum Load capacity as follows:

PART	NAME	MAXIMUM WEIGHT CAPACITY
5	Top shelf	20 lbs
6	Adjustable Shelf	15 lbs
11	Fixed shelf	20 lbs
12	Bottom shelf	20 lbs
8	Towel Bar	15 lbs




Save these
instructions.

Step 1

Build Cam Bolts and Magnet

- Lay the Left panel ①, Right panel ②, Top shelf ⑤ flat on the floor. Note the hole locations following the below diagram.
- Tighten 18x Cam Bolts (A) to Left panel ①, Right panel ② and Top shelf ⑤ at the specified locations using a Phillips screwdriver.
- Fasten Magnet (E) to Top shelf ⑤ with 2X Screws (H) and tighten with a Phillips screwdriver.



Phillips Screwdriver
needed. Not included

A	x18	H	x2	E	x1
					




Save these
instructions.

Step 2

Assemble Door Accessories

- Fasten 4X Metal Hinges (K) to Left Door ③ and Right Door ④ with 8X Screws (H) and tighten with a Phillips screwdriver.
- Fasten 2X Magnet Plates (G) to Left Door ③ and Right Door ④ with 2X Screws (H) and tighten with a Phillips screwdriver.
- Fasten 2X Knobs (D) to Left Door ③ and Right Door ④ with 2X Screws (H) and tighten with a Phillips screwdriver.



Phillips Screwdriver
needed. Not included


J	x2	D	x2	H	x10	G	x2	K	x4
									



Save these
instructions.

Step 3 Build Cross Bar, Shelves, Towel Bar and Back Panel

- Insert 3x Wood Dowels (C) to Upper cross bar ⑬, Lower shelf ⑪ and Bottom shelf ⑫ at the specified locations.
- Insert 7x Cam Locks (B) to Upper cross bar ⑬, Lower shelf ⑪, Bottom shelf ⑫ and Lower cross bar ⑦ at the specified locations.
- Carefully align Wood Dowels (C) to pre-drilled holes, Cam bolts (A) to Cam Locks (B) and Towel Bar ⑧ to the pre-drilled hole.
- Connect Upper cross bar ⑬, Lower shelf ⑪, Bottom shelf ⑫, Lower cross bar ⑦ and Towel Bar ⑧ to Left panel ② by turning all 7x Cam Lock (B) to engage. Following Cam Lock safety precautions
- Insert Lower back panel ⑩ into the grooves at Lower shelf ⑪ and Bottom shelf ⑫.



A buddy is helpful for assembly.



Phillips Screwdriver needed. Not included



Follow the Cam Lock safety precautions


B	x7	C	x3
			



Save these instructions.

Step 4 Build Cross Bar, Shelves, Towel Bar and Back Panel

- Insert 3x Wood Dowels (C) to Right panel ① at the specified locations.
- Insert 7x Cam Locks (B) to Upper cross bar ⑬, Lower shelf ⑪, Bottom shelf ⑫ and Lower cross bar ⑦ at the specified locations.
- Carefully align Wood Dowels (C) to pre-drilled holes, Cam bolts (A) to Cam Locks (B) and Towel Bar ⑧ to the pre-drilled hole.
- Connect Upper cross bar ⑬, Lower shelf ⑪, Bottom shelf ⑫, Lower cross bar ⑦ and Towel Bar ⑧ to Right panel ① by turning all 7x Cam Lock (B) to engage. Following Cam Lock safety precautions



A buddy is helpful for assembly.



Phillips Screwdriver needed. Not included



Follow the Cam Lock safety precautions

B	x7	C	x3
			






Save these instructions.

Step 5

Assemble Back Panel and Connect Top Shelf

- Carefully turn your assembled unit upright.
- Unfold back panel ⑨.
- Insert Upper Back panel ⑨ into grooves at assembled unit.
- Insert 2x Wood Dowels (C) to Right Panel ① and Left Panel ② at the specified locations.
- Insert 4x Cam Locks (B) to Right Panel ① and Left Panel ② at the specified locations.
- Carefully align Wood Dowel (C) to Pre-drill holes, Cam Bolts (A) to Cam Locks (B).
- Connect Top shelf ⑤ to Right Panel ① and Left Panel ② by turning all 4x Cam Lock (B) to engage. Following Cam Lock safety precautions.



Phillips Screwdriver
needed. Not included



Follow the Cam Lock
safety precautions

B	x4	C	x2
			




Save these
instructions.


Step 6

Build Adjustable Shelf

- Locate the desired spacing for your adjustable shelf.
- Insert 4x Shelf Holders (L) to Left panel ①, Right panel ② the pre-drill holes at your desired spacing
- Insert Adjustable shelf ⑥ on top of the Shelf Holder (L)



A buddy is helpful for assembly.




Save these instructions.


Step 7

Build Doors to Cabinet

- Fasten Right Door ③ and Left Door ④ to Right Panel ① and Left Panel ② with 8X screws (H) and tighten with a Phillips screwdriver.



Phillips Screwdriver
needed. Not included




Save these
instructions.



Anchor Instructions

- Locate solid wood studs to mount the anchor to. It is important that the screws are firmly embedded into the wood stud. In cases of thick drywall or wall plaster, you may have to purchase longer screws.



Screwing only into the drywall is not enough and could result in personal or property injury, damage or harm



Save these instructions.

Step 8 Stick Screw Hole Covers and Build Cabinet to Wall

- Stick the screw hole covers (M) to cover the visible screw holes.
- Plug in plastic anchor (I) into the wall.
- Insert screws (F) through the pre-drilled hole on back panel ⑨ upper cross bar ⑬ into plastic anchors and tighten with a Phillips



Phillips Screwdriver
needed. Not included



A buddy is helpful
for assembly.

M	x16	F	x2	I	x2



Save these
instructions.

Care & Maintenance

- Regularly check all fastenings to ensure that they are properly tightened.
- Clean with a damp soft cloth, then use a soft lint free cloth to dry.
- Hot or wet items should not be placed directly on the furniture surface.
- Do not clean furniture with harsh cleaners or polish.
- Do not place furniture in direct sunlight or near heating/cooling vents.
- To protect the surface, use a pad when writing on top of the furniture.
- For indoor residential use, do not place furniture outside.
- Do not stand on the product or use as a step ladder
- Children should not climb on furniture.

