Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please see the End Table section to find the hardware.














END TABLE

N770P542323



CAUTION: This End Table is NOT a TOY.
Keep your child / children at bay in the process of assembly.
For turning the End Table and to prevent damage to the End Table.
02 persons may be needed to execute this action.

PARTS LIST: N770P542323

①	Left side panel 	1PC
②	Right side panel 	1PC
③	Bottom panel 	1PC
④	Top panel 	1PC
⑤	Back panel 	1PC
⑥	Front panel 	1PC
⑦	Short bar (leg) 	2PCS
⑧	Long bar (leg) 	1PC
⑨	Drawer front 	1PC
⑩	Left drawer side 	1PC
⑪	Right drawer side 	1PC
⑫	Drawer bottom 	1PC
⑬	Drawer back 	1PC


Hardware (Each of the above hardware Including exxtra 1 pc)

Label	Picture	Description	Q.ty
A		Wood dowels Ø6 x 25	14+ 1
B		Wood screws M4 x 40	9 + 1
C		Wood screws M3.5 x 25	8 + 1
D		Wood screws M3.5 x 15	7 + 1
E		Wood screws M4 x 25	16 + 1

HARDWARE LIST: N770P542323

Assembly Preparation

Before Begining Assembly




 *14 + 1

 *7+1

 *9 + 1

 *16+1


 *8 + 1



ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)

- Read instructions, cover to cover-
- Have 2 adults on hand for assembly-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-


Overview



FRONT FACING


This End tabble has multiple parts and may require up to some 30 minutes to assemble.
To give you an overview of the end table parts, the above picture is to help you put the various parts into perspective .
Please read through the instructions here below to familiarise the parts and steps before assembly.

STEP 1




Unpack and place all part on a clean, non-marring surface.

STEP 2




Insert 4 pcs of Wood dowels Ⓐ to secure Bottom panel ③ to Left side panel ① & Right side panel ②.
Then, use 6 pcs Wood screws Ⓔ to tighten. *Do not overtighten*.

STEP 3




Insert 4 pcs of Wood dowels Ⓐ to secure Bottom panel ③ to Left side panel ① & Right side panel ②.
Then, use 6 pcs Wood screws Ⓔ to tighten. *Do not overtighten*.

STEP 4




Attach Back panel⑤to Left side panel①, Right side panel②, and Top panel④. Then, use 7 pcs of Wood screws Ⓓ to tighten.

STEP 5




Insert 2 pcs of Wood dowels Ⓐ to secure Front panel⑥to Bottom panel③. Then, use 4 pcs Wood screws Ⓔ to tighten. *Do not overtighten*.

STEP 6




Insert 4 pcs of Wood dowels Ⓐ to secure Short bar (leg) ⑦ to Bottom panel ③. Then, use 6 pcs Wood screws Ⓑ to tighten. *Do not overtighten*.

STEP 7



Position Long bar (leg) ⑧ in front of Short bar (leg) ⑦, aligning their ends with the outer face of Short bar (leg) ⑦. Then, use 3 pcs of Wood screws Ⓑ to tighten. *Do not overtighten*.

STEP 8



Attach Left drawer side ⑩ and Right drawer side ⑪ to Drawer front⑨ Then, use 4 pcs of Wood screws Ⓒ to tighten.

STEP 9




Figure 1




Figure 2

Gently slide Drawer bottom ⑫ down into the grooves of Left drawer side ⑩ and Right drawer side ⑪. (Figure 1).

Align the groove of Drawer back ⑬ with Drawer bottom ⑫ , Left drawer side ⑩ , and Right drawer side ⑪. Then, use 4 pcs of Wood screws Ⓒ to tighten. (Figure 2).

STEP 10




Figure 1





Figure 2

Insert drawer into cabinet and close. Release lever will lock. Finished. (Figure 1).

Press release lever. Remove inner rail from outer rail. (Figure 2).

COMPLETED



Inspect the End Table an make sure all parts are adequately connected.
Your end table is ready for use.

CARE INTRUCTIONS:
Hardware may loosen overtime. Periodically check that all connections are tight.
Wipe with a soft , dry cloth . To protect finish , avoid the use of chemicals and household cleaners.