

COMPRESSION SOFA



To fully enjoy the comfort and functionality of your new sofa, please follow these steps to restore it to its original shape after unboxing:

- 1. Pat the Sofa: Gently pat each side of the sofa multiple times to help it regain its shape. Start with one side, then repeat the process on the opposite side.
- 2. Flip the Sofa: Turn the sofa over and repeat the patting process to ensure even reshaping on all sides.
- 3. Rotate the Sofa: Rotate the sofa 180 degrees, then continue patting to further restore its original form.
- 4. Lightly Tap and Press: Gently tap, knock, and press on the sofa to help it regain its original shape and enhance overall comfort.
- 5. Smooth the Fabric: If wrinkles appear on the fabric, use a garment steamer to smooth them out for a more refined look.

NOTICE

- 1. Due to compression during packaging for more efficient shipping, the fabric may develop wrinkles. These wrinkles will gradually fade away over time.
- 2. Please be patient as the sofa returns to its fully fluffed state, which typically takes between 72 hours and one week.

If you are experiencing any issues, such as insufficient rebound height, fabric wrinkles, fabric color variation, incorrect sofa orientation, or if you need more assistance, please feel free to contact our customer service team.

