

Parts Included EN



1*
Shaker



1*
Bar spoon




1*
Brush




1*
Muddler



1*
Ice tong



2* Spoon
2* Straws



1*25/50
jigger



1*15/30
Jigger



1*
Ice strainer



2*
Wine pourers



2*
Bottle stopper



1*
Corkscrew



1*
Sieb



4*
Fruit needle



4*
Bolts



8* Nuts
16* rubber ring




1*
RECIPE BOOK




1*
Detachable
acrylic stand


Installation Steps




1. please tear up the protective film




2. Put the bolts and rubber ring into the connection holes of the bottom tray



3. Tighten the nuts and the bolts



4. Align the connection holes of the upper tray with nuts (Pay attention to the tray's alignment of the upper and lower holes, please don't install upside down)



5. Tighten the nuts and the bolts above



6. Put all the accessories into the Acrylic stand orderly