









Assembly Instruction--Accent Chair

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. It is recommended that 2 people work together during assembly to prevent personal injury and to ensure that heavy or cumbersome parts are not damaged during the process.

PARTS #	PARTS NAME	DRAWING	QTY
A	FRONT LEGS		2
B	BACK LEGS		2
C	CHAIR		1
D	BOLT		12
E	WASHER		12
F	WASHER		12
G	WRENCH		1

1. Place the chair body out of the box and remove the dust cover. Take out Legs and plastic washer under the cushion. Turn down the chair.



2. Screw the leg into the threads inserts of the frame. Repeat the procedure with the other legs. Check that all legs are secure. **3. Level the chair and place the chair upright on a level surface. Assembly is complete.**

