









ASSEMBLY INSTRUCTION






ASSEMBLY INSTRUCTION




Part List

A  Leg (HB Font) - 2pcs	B  HB Frames - 1pcs	C  FB Frames - 1pcs
D1  Side Rails - 2pcs	D2  Side Rails - 2pcs	E  Leg (FB Back)- 2pcs
F  Slats - 10pcs	G  Middle leg - 2pcs	



Hardware List


1	 1/4" x 100mm Hex-Head bolts 4pcs	2	 Allen Key 1pcs	3	 1/4" x 40mm Hex-Head bolts 14pcs
4	 1/4" x 30mm Hex-Head bolts 11pcs	5	 M4 x 30 mm Wood Screws 20pcs		




Assembly Tools Required (Not Included)


STEP 1: Following below illustration:

1	3
	
4pcs	6pcs



STEP 2: Following below illustration:


4

8pcs




X2

STEP 3: Following below illustration:





3



8pcs



STEP 4: Following below illustration:



FINISH

