


ASSEMBLY INSTRUCTIONS



721110
ITEM: **721110**

ITEM:721110

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

(A) TOP




1 PC

(B) SHELF




1 PC

(C) BOTTOM PANEL




1 PC

(D) LEFT SIDE PANEL




1 PC

(E) RIGHT SIDE PANEL




1 PC

(F) LEFT DIVIDER PANEL




1 PC

(G) RIGHT DIVIDER PANEL



1 PC

(H) SMALL LEFT SIDE PANEL




1 PC

ITEM:721110


PARTS IDENTIFICATION

(I) SMALL RIGHT SIDE PANEL




1 PC

(O) RIGHT INNER CROSSBAR




1 PC

(J) LEFT BACK PANEL




1 PC

(P) LEFT OUTER CROSSBAR




1 PC

(K) RIGHT BACK PANEL




1 PC

(Q) RIGHT OUTER CROSSBAR




1 PC

(L) FRONT LONG CROSSBAR




1 PC

(R) FRONT LEFT CROSSBAR




1 PC

(M) REAR LONG CROSSBAR




1 PC

(S) FRONT RIGHT CROSSBAR



1 PC

(N) LEFT INNER CROSSBAR



1 PC












(T) LEFT LEG



1 PC












ITEM: 721110

PARTS IDENTIFICATION

(U) LEG CROSSBAR		1 PC	(E1) DRAWER BACK PANEL		2 PCS
(V) RIGHT LEG		1 PC	(F1) DRAWER BOTTOM PANEL		2 PCS
(A1) UPPER BACK PANEL		1 PC	(G1) DRAWER BOTTOM SUPPORT		2 PCS
(B1) LOWER BACK PANEL		1 PC	(H1) UPPER DRAWER FRONT		1 PC
(C1) DRAWER LEFT SIDE PANEL		2 PCS	(I1) LOWER DRAWER FRONT		1 PC
(D1) DRAWER RIGHT SIDE PANEL		2 PCS			

ITEM:721110


HARDWARE IDENTIFICATION

1	LARGE CAMBOLT	L=29mm		39pcs
2	LARGE CAMLOCK	ø15mm		39pcs
3	SMALL CAMBOLT	L=20mm		8pcs
4	SAMLL CAMLOCK	ø12mm		8pcs
5	SHORT DOWEL	ø8 × 25mm		36pcs
6	LONG DOWEL	ø6 × 30mm		4pcs
7	HANDLE	96mm		2pcs
8	HANDLE SCREW	ø4x22mm		4pcs
9	FLAT-HEAD SCREW	M6 × 25mm		2pcs
10	LARGE SCREW	ø4x30mm		12pcs
11	EXTRA LARGE SCREW	ø4x45mm		12pcs
12	WOOD SCREW	ø7x48mm		4pcs
13	WASHER	ø8xø16x2mm		4pcs
14	STICKER	ø20mm		10pcs
15	NAIL	Z1016		66pcs
16	GLUE			1pc


ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8 COMPLETE




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 9




STEP 10 COMPLETE




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 11




STEP 12 COMPLETE




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 13




STEP 14 COMPLETE




ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 15




STEP 16 COMPLETE



ITEM: 721110

ASSEMBLY INSTRUCTIONS

STEP 17



STEP 18 COMPLETE

