


Power Recliner Chair


Friendly Reminders:

1. Patience with cushions – The cushions are vacuum-sealed and may arrive wrinkled. Smooth creases with an iron, or fluff up seat & back cushions by gentle tapping.
2. Please check all parts first before unpacking & assembly. Verify complete & undamaged accessories prior to installation.
3. Need help? – If any parts are missing or damaged (please take photos for reference), feel free to contact us. Our support team will assist you promptly!


Thank you for choosing us – your comfort zone starts here!



PARTSLIST


Seat Cushion  Ax1pc	Backrest  Bx1pc	Armrest (CL/CR)  CL CR	Power Adapter  Dx1pc
Power Cord  Ex1pc	Hand Remote  Fx1pc	Feet  Gx4pc	
Screws  Ix6pc	Allen Key  Jx1pc		

STEP1




Align armrest CL & CR holes
with seat(A), then tighten screws(I).

STEP2




Install feet (G) sequentially
at the bottom of the seat frame.

STEP3



Align the backrest(B) with metal connector, fully insert and set upright.

STEP4



Connect power adapter(D),
hand remote(F) and power cord(E) in order.

STEP5

WARM TIPS:

Press hand remote UP: backrest Lowers, footrest Lifts automatically.

Press hand remote DOWN: backrest Rises, footrest Lowers automatically.

