



Bakers Sideboard BSB1

If you need assistance, please call 1-877-ENCLUME
Enclume Design Products
24 Colwell Street, Port Hadlock, WA 98339



Enclosed you will find everything needed for the assembly and use of your Baker's Sideboard. Two people make assembly and installation easier. Unpack and identify all the parts before you begin.

The parts and hardware included are:

- 2 – Rectangular uprights with feet attached
- 1 – Butcher block work surface
- 1 – Butcher block top shelf
- 1 – Steel trim band
- 2 – Shelf rims
- 2 – Curved upper shelf support brackets with $\frac{3}{8}$ " x $\frac{3}{4}$ " button head screws attached
- 2 – Grid shelves
- 10 – $\frac{1}{4}$ " x $\frac{7}{8}$ " button head screws
- 20 – $\frac{1}{2}$ " button head screws
- 1 – Utensil bar
- 2 – 2 $\frac{1}{2}$ " lag bolts
- 1 – 5/32" Allen wrench (small)
- 8 – Utensil hooks
- 1 – 7/32" Allen wrench

Assembly and Installation Instructions

- 1) Lay the rectangular uprights side by side on the floor in the correct relationship to one another, about 24" apart.
- 2) Notice the rivet placement on the shelf rims. When the rims are right side up the rivets are positioned closer to the bottom of the shelf rim than the top. This positioning allows the grid shelves to seat deeply inside the rim. Slide one of the shelf rims *inside* the rectangular uprights. Attach the rim to the uprights using 8 – $\frac{1}{2}$ " button head screws. The button heads should be inserted front to back so the head is visible from the outside of the sideboard. **Leave the screws loose.**
- 3) Repeat Step 2 for the second shelf rim.
- 4) Attach the steel trim band to the *outside* of the rectangular uprights using the last four $\frac{1}{2}$ " button head screws.
- 5) Stand the base on its feet.
- 6) Square up the base and tighten all the screws.
- 7) Slide the grid shelves into the middle and lower shelf rims with the long wires facing upward.
- 8) Put the butcher block work surface on top of the unit. The back of the board should be flush with the back of the rectangular uprights. Align the holes on the bottom of the work surface with the slots on the top of the rectangular uprights. Attach the pieces together with four $\frac{1}{4}$ " x $\frac{7}{8}$ " button head screws and the small Allen wrench.
- 9) Place the shelf brackets on top of the work surface, aligning the holes in the brackets with the holes in the work surface. Attach the pieces together with four more $\frac{1}{4}$ " x $\frac{7}{8}$ " button head screws.
- 10) Put the butcher block top shelf on the top of the shelf brackets aligning the holes in the bottom of the shelf with the slots on the top of the supports. Attach them together with the last two $\frac{1}{4}$ " x $\frac{7}{8}$ " button head screws.
- 11) Remove each of the $\frac{3}{4}$ " button head screws which have been inserted in the shelf brackets. Place the utensil bar over the place of attachment and screw back together. Hang the hooks from the bar.
- 12) We recommend the sideboard be placed tightly against a wall. The two 2 $\frac{1}{2}$ " lag screws are for attaching the rack to the wall should you wish to do so. Four extra holes have been drilled in the back of the steel trim band. The holes are drilled on 16" x 32" centers to match standard wall stud placement. If the positioning of the holes does not match those of your wall studs, you may drill new holes in the trim to align the rack.
- 13) The butcher block surface has been penetrated with natural mineral oil. To main the finish, we recommend a periodic application of mineral oil rubbed into all the wooden surfaces.

WARNING: It is important that your Baker's sideboard is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

LIMITED WARRANTY: This product is warranted to be free of material defects, other than that from normal use, for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, postage prepaid within 20 days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.