

# ASSEMBLY INSTRUCTION









## LOVE SEAT WITH 6 PILLOWS




Legs and hardware are stored at the bottom of love seat, please take out the legs and hardware for assembly.

**NOTE:** Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.


### COMPONENT LIST (LOVE SEAT)

NO·	DRAWING	QTY	DESCRIPTION
A		1	Love seat
B		2	Seat cushion
C		4	Pillow (20x20")
D		2	Pillow (15x15")
E		4	Wooden leg (6&7x2x2.4")
F		4	Bolt (ØM8x60mm)
G		4	Flat washer (ØM8)
H		1	Allen Key (ØM8)


# Step1



# Step2



### Step3



#### Care Instruction

In order to maintain the original appearance of your furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage furniture.
- Do not place your upholstered furniture too close to windows, radiators, or vents and be sure to use window, radiators, or vents.
- Vacuum or wipe with a soft brush to remove dust.



For items used on wooden floor, hard surfaces or carpets, it is recommended to install protected pads under all legs supports to avoid/prevent from damages/ scratches discoloration.