User Manual

Solar Motion Sensor Light

Dear customer, thank you for your interest in Exgreem solar lights. We are committed to providing the most detailed user instructions to every customer who is interested in Exgreem lights. Please read the following instructions carefully.

Features

- * Premium Solar Lights Ready for All Weather
- * Eco-friendly & Energy Saving
- * Sensitive Motion Inductor
- * The 208 LED Solar Lights have 3 Modes
- * 18 Higher Charging Conversion Rate
- * 208 LED Ultra-Bright Outdoor Solar Light
- * 270°Wide Beam Angle & Large Coverage
- * Wire-Free & Simple Installation

Specifications:

EXGREEM Solar Motion Sensor Light Material ABS Life Span 50000 (h) Lithium battery 3600mAh Power Source Solar Product Size 4.87*3.73*1.89 Black Color inch Led Bulbs 208 LED per Light Waterproof Rating IP65 Waterproof Sensor Mode Motion detection + Wattage 5.2 watts Light sensor 3.7 Volts Sensitivity distance 3-8M (10ft - 26ft) Voltage Working Time 8-12Hours **Special Features** Motion sensor, Wide Angle Illumination, Waterproof Wall Light

Package Content

Solar motion sensor light x 1 \sqrt{M} Mounting Accessories Kit x 1 \sqrt{U} ser manual x 1

Warming Tips:

1. For optimum battery performance, please allow the batteries to full charge for 2 or 3 sunny days before turning the lights on for the first time.

2. Emergency Light Mode: If you press the switch button for more than 3 seconds, It will enter emergency lighting mode, Which mean the solar light will remain bright and it can be applied to the scene requiring emergency lighting. At this time, It consumes electricity fast and it can about last for 3-5 hours.

3. Please put the lamp under the sun for several hours, To collect as much as power, Please install the solar panel towards the sun as much as possible.

4. When the light is flashing or the icon is not lit when you press the button, It means low battery.

5. When using it for the first time, please charge it for several hours under the sun.



Product size chart