
# INSTRUCTION MANUAL


## Wreath Decorations



**PRE-ASSEMBLY:**
**PARTS LIST**

- Ensure there are no missing pieces pieces by firstly separating and identifying all parts before assembling.
- Make sure to check packing material for small parts when shipment received to avoid any parts missing during shipment.

| Part | Description | Illustration | Qty |
|---|---|---|---|
| A | Wreath |  | 4 |

| | | | |
|---|---|---|---|
| **B** | **Bow** |  | **2** |
| **C** | **Zip Tie** |  | **12** |

## TIPS :


- To ensure the final unit is secure and sturdy, it is highly recommended to secure each component with the zip ties provided after connecting each component together in the steps.
- Remove all components from the box and lay flat on the floor before assembling to make it easier for you to assemble accordingly.
- Some parts are connected by a string of lights and should NOT be separated. Any separation or disconnection of the light set may cause the unit to malfunction or not light completely.


## Assembly:
## MAKE SURE TO FOLLOW THE STEPS STRICTLY FOR A SUCCESSFUL & EASY ASSEMBLY

1. Remove all components from the box & packaging and lay flat them on the floor to make it easier for you to assemble later.


**NOTE:** Parts are connected by a string of lights and **SHOULD NOT** be separated. Any separation or disconnection of the light set may cause the unit to malfunction or not light completely.

2. Connect 2 piece of the bow, connect 4 piece of the wreath. Secure them by zip ties.







3. Hang assembled bow to top of the wreath.Secure with zip ties.



4. **VERY IMPORTANT**: Secure the installing points with plastic ties(C).
5. Connect the plug to the extension cord with A to A, B to B... and plug the light set into a standard 120-volt AC electrical outlet.



**Warning :**

- Product may contain glitter, DO NOT assemble indoors to avoid unintended property cleanup.
- DO NOT plug into a wall outlet until item is fully assembled and lights are properly connected.
- DO NOT use in extreme weather conditions.
- This item is NOT intended for permanent installation or use.
- Unplug item when not in use or if left unattended.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made .
- DO NOT allow glitter to contact your eyes or face as this may result in skin irritation or injury.
- Keep items away from all heat sources ( fireplace, stove, heater, etc.).
- Do not secure wiring with staples, nails, or sharp hooks.
- Do not hang ornaments or other obiects from the cord.

# Troubleshooting Guide

| Problem | Solution |
|---|---|
| Unstable or Difficult to Assembly | Ensure the product is placed on a flat, level surface |
| Malfunctioning Operation | Verify the product is securely plugged into a wall outlet or a UL-listed power cord;Do not plug into other electrical items. |
| Product Fails to Light Up | Inspect for loose/broken bulbs, faulty connections, or unplugged cords; |
| Partial Lighting (Multiple Light Strings) | If the product has multiple light strings, make sure all power cords are correctly connected to the power supply (e.g., A is connected to A, B is connected to B). |

# Care and Help Center

Question? Concerns? We'd love to hear them!
E-mail: jinmai211211@gmail.com and we will reply within 24 business hours.

# ⚠WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.