


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Hammer

(Not Included)



Philips Screwdriver

(Not Included)



**2 - Persons
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3


Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.

Drawer Cabinet



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS


A1PC



B1PC



C1PC




D1PC




E1PC




F1PC




G2PCS




H2PCS



I2PCS



J2PCS



K2PCS




HARDWARE

① 16PCS ② 16PCS ③ 16PCS




④ 8PCS ⑤ 4PCS ⑥ 11PCS



ACCESSORIES

A1 2PCS A2 2PCS A3 1PC



A4 1PC A5 1PC A6 1PC A7 1PC A8 2PCS




A9 1PC




GET READY

Please group boards as below.



Drawer



Body


ASSEMBLY INSTRUCTIONS

1


Hardware ① x 8PCS

Hardware ③ x 8PCS


Accessory **A3** x 1PC




X 2



X	2
---	---



X 2



OPTIONAL

Apply a dab of glue into dowel holes of panels before inserting dowels (#3).

2

Part **G** x2PCSPart **H** x2PCS

Part I x2PCS

Part J x2PCS




Part **K** x2PCS

Hardware ② x 8PCS



Hardware ④ x 8PCS

Accessory (A1)x 2PCS

Accessory (A2) x 2PCS



X 2



Please refer to Page 5 for detailed instructions on how to fasten cam locks (#2) to cam bolts (#1).


ASSEMBLY INSTRUCTIONS

3

Hardware ① x 8PCS

Hardware ③ x 8PCS

Accessory A3 x 1PC



ASSEMBLY INSTRUCTIONS




4

Part **B** x1PC

Part **D** x1PC

Part **E** x1PC



Hardware ② x 2PCS



5

Part **C** x1PC

Hardware ② x 2PCS




ASSEMBLY INSTRUCTIONS

6

Part **F** x1PC


Hardware **⑥** x 11PCS



7

Part **A** x1PC





Hardware **②** x 4PCS



ASSEMBLY INSTRUCTIONS

8

Hardware ⑤ x 4PCS



ASSEMBLY INSTRUCTIONS

9

Part **A** x1PC

Accessory **A4** x 1PC



Accessory **A5** x 1PC

Accessory **A6** x 1PC

Accessory **A7** x 1PC

Accessory **A8** x 2PCS

Accessory **A9** x 1PC



10

ASSEMBLY COMPLETED




Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE



Yearly
Check

We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.