


1. Installation method




Step 1:

Place the metal plates on the magnetic area of the light.



Step 2:

For a more secure fixation, use screws to attach the metal plate.




Step 3:

Press the light firmly onto a clean, dry surface and hold for 10 seconds to secure.


2. How to use

① Remote control



1. Remove the battery insulation film before use.
2. Follow the directions on the back of the remote control if you need to replace the battery.

② Product



Switch

Short Press: Change the color temperature
Long Press: Stepless dimming

Indicator Light

Green: Fully Charged
Red: Charging

NOTE: Please fully charge the lights before use for the first time.

3. Product Parameters

Working Voltage: 5V=1A

Power: 1.6W

Material: ABS+PC

Color Temperature:

White light/ Warm light/ Neutral light

Charging Method: Type-C

Product Dimensions: 3.15*3.15*2.76inches

4. Attention

- If the light becomes dim, please charge it in time.
- These lights are non-waterproof. Install them in locations away from moisture and excessive heat.
- Do not allow children to use the lights as toys to prevent accidents.
- During the warranty period, refrain from disassembling the product without permission if issues arise, as this action may void the warranty.
- Please use a regular charger with a USB port for charging. The rated voltage of the charger is DC5V, and the current is ≤ 1 amps. Do not use fast charging to avoid affecting the battery life.
- Disconnect the charger once the battery is fully charged. If storing the product for an extended period, keep the battery at a moderate charge level (Avoid full discharge as it reduces battery life.)

5. Warranty

Thank you for your purchase! We offer a 24-month warranty for our products. If you encounter any issues, please contact us on Amazon, and we will assist you promptly within 24 hours.