


Metal Dining Table Assembly Manual




- Prior to assembly, please confirm all of the parts listed included.
- All bolts should be tightened before use. Maybe, you need allen wrench for assembly.
- Missing part? Damaged?
 Contact us via email at service@domioutdoorliving.com







Attention:

Put a mat under to minimize the scratching of the table during installation. The openings of Parts ① are equipped with **plastic plugs** to prevent deformation. When ready to install, please ensure to **remove** these plastic plugs from Parts ①.






Insert Parts ③ to Parts ① and place Part ② as shown. Then Put two Parts ① together completely.



Secure the tabletop with 4 part ⑦, 4 screws ® and 4 nuts ⑨ as shown.

Please don't fully tighten the screws before all the kits are connected in this step.



Assemble Table top to the 4 legs with washers and screws . After all screws are assembled in place, tighten them together.

Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and

friendly, casy-to-reach after-sales service. So if you

have any questions about our product and assembly-

,please feel free to contact us. We will be here for you.

Support:





After-sales contact email:

service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.