

Simple Style, Unfading Life



Important:

1. It is recommended that customers use an electric screwdriver to install, it will be easy to assemble.
2. The metal frames have certain degrees of elasticity. Please DO NOT over tighten the screws during assembly. An over tightened screw can cause bent metal frame.
3. For a smooth assembly process, we suggest you keep a lite tightness for all the screws during assembly, after the whole dresser is aseembled , firmly tightening all the screws.

Thank you for choosing our product.
































Please kindly share your shopping experience if you are satisfied with it. If you have any problem regarding assembling or product itself, please just contact us.

We will do everything we can do to solve all the problem for you.

Exploded Drawing




Parts:


1  X1	2  X1	3  X1	4  X2	5  X2
6  X1	7  X1	8  X2	9  X1	10  X1
11  X2	12  X4	13  (L) X9	14  (R) X9	15  X1
16  X1	17  X3	18  X6		
A  X4	B  X4	C  M6X10 X8	D  M6X23 X18	E  M5X40 X20
F  M4X10 X18	G  M4X12 X2	H  M6 X6	J  X9	K  X1
L  M6X30 X2 M4X50 X2	 M4	 M3		

Assembly Instruction:

STEP1




STEP2



There are 4 metal nuts on part 10, which are facing back when install them. You can see in step 10 .


Assembly Instruction:

STEP3




Assembly Instruction:


STEP5



STEP4




STEP6




Assembly Instruction:

STEP7




STEP8




Assembly Instruction:

STEP9




STEP10




Assembly Instruction:

STEP11




Assembly Instruction:


STEP13



STEP12




STEP14



Assembly Instruction:

STEP15



More Options:



3-Drawers Rustic Nightstand 1PCS
40X39X68cm
15.75”X15.35”x26.77”



3-Drawers Rustic Nightstand 2PCS
40X39X68cm
15.75”X15.35”x26.77”

STEP16



3-Drawers Nightstand 1PCS
40X39X68cm
15.75”X15.35”x26.77”



3-Drawers Nightstand 2PCS
40X39X68cm
15.75”X15.35”x26.77”

More Options:



4-Drawers Rustic Dresser
100X30X52cm
39.37"X11.81"x20.47"



4-Drawers Rustic Nightstand
55X30X67.5cm
21.65"X11.81"x26.57"



8-Drawer Ladder Shapen Dresser
95.5X29X106.5cm
37.6"X11.4"x41.9"



10-Drawer Dresser
100X30X98cm
39.4"X11.8"x38.6"

GENERAL GUIDELINES:

- Please read the following instructions carefully and use the product accordingly.
- Please keep this instruction and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps.
- Please contact us when further information and help are needed.

NOTES:

- The product is intended for normal use only. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- Keep away from exposure and heat sources. Place it in a dry area to avoid peeling or fading.
- Please check if there is any welding spatter or debris when you receive the product.
- If there are defective or missing parts after unpacking, please contact us immediately.
- Use soft cloth and neutral detergent to wipe it clean, then wipe dry. Do not use an abrasive agent to wipe the product.

WARNINGS:

- During assembly, keep small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- To avoid potential danger of suffocation, keep all parts and packaging (films, plastic bags and foam, etc.) away from babies and children.
- Keep away from sharp or corrosive items to avoid potential product damage or bodily injury.